


EAC 30

Control panel



Instruction manual

1	INTRODUCTION	5
1.1	Language	5
1.2	Control panel	5
1.3	Controls	6
1.4	First steps	9
	1.4.1 Display	9
	1.4.2 Select language	10
	1.4.3 Unit of measurements	10
2	TECHNICAL DATA	12
3	MENU	13
3.1	Menus	13
3.2	Home menu	13
3.3	Configuration menu	13
3.4	Tools menu	14
3.5	Weld setting menu	14
3.6	Measurement menu	15
3.7	Memory menu	15
3.8	Fast mode menu	16
4	SUBMERGED ARC WELDING (SAW)	17
5	GAS METAL ARC WELDING (GMAW)	18
6	GOUGING	19
7	ELECTRO SLAG WELDING	20
8	JOINT-TRACKING	21
8.1	Joint-tracking with edge control	21
8.2	Joint-tracking with groove control	22
8.3	Joint table	22
8.4	Position for welding start	23
8.5	Positioning for welding start (with inductive joint-tracking)	24
9	FUNCTION EXPLANATIONS	25
9.1	CA, constant amperage	25
9.2	CW, constant wire feed	25
9.3	CC, constant current	25
9.4	Wire / electrode dimension	25
9.5	Arc voltage	25
9.6	Wire feed speed	25
9.7	ICE wire feed speed	25
9.8	ICE wire start delay	26
9.9	Travel speed	26
9.10	Welding direction	26
9.11	AC frequency	26
9.12	AC balance	26
9.13	AC offset	26
9.14	Flux pre-flow (SAW)	26
9.15	Gas pre-flow (GMAW)	26

9.16	Start adjust	27
9.17	Air pre-flow (Gouging)	27
9.18	Start type	27
9.19	Wire creep start	27
9.20	Start phases	27
9.21	Flux post-flow (SAW)	28
9.22	Gas post-flow (GMAW)	28
9.23	Air post-flow (Gouging)	28
9.24	Crater filling	28
9.25	Burnback time	28
9.26	Stop phases	28
9.27	Regulation parameters	29
9.28	Setting limits	29
9.29	STEP function	30
9.30	Intermittent welding	31
10	MEMORY MANAGEMENT	32
10.1	Control panel working method	32
10.2	Storing a set of weld data	32
10.3	Recalling a stored data set	33
10.4	Deleting data set	34
10.5	Copying content of a weld data set to a new memory position	35
10.6	Naming a stored weld data set	36
10.7	Editing content of a weld data set	37
11	CONFIGURATION MENU	38
11.1	Code lock	38
	11.1.1 Lock code status	38
	11.1.2 Specify/edit lock code	39
11.2	General configuration	39
	11.2.1 Fast mode soft buttons	39
	11.2.2 Quality data log to file	40
	11.2.3 Soft key configuration	40
	11.2.4 Auto save mode	42
11.3	Machine configuration	43
	11.3.1 Product code	43
	11.3.2 Wire feed axis 1	44
	11.3.3 Wire feed axis 2	44
	11.3.4 Travel axis	45
	11.3.5 External axis	45
	11.3.6 Tandem	46
	11.3.7 Parallel power sources	47
	11.3.8 ICE wire feed	48
	11.3.9 Node id settings	49
	11.3.1 System information	
	0	50

TABLE OF CONTENTS

11.4	Maintenance	50
11.5	Network settings	50
11.6	Measure-values filter factor	51
12	TOOLS MENU	52
12.1	Event handling	52
	12.1.1 Event log	52
	12.1.2 Active errors	52
12.2	Export Import	53
12.3	File manager	53
12.4	Production statistics	55
12.5	Quality functions	55
12.6	Calender	56
12.7	User accounts	57
12.8	Unit information	57
13	ERROR CODES	59
13.1	High temperature	59
13.2	Low welding current	59
13.3	Low battery voltage	59
13.4	Speed error on a motor (wire feed, travel motor)	59
13.5	Lost contact with the unit	59
13.6	High welding current	59
13.7	Current servo saturation	59
13.8	Current servo saturation	60
13.9	High DC voltage	60
13.10	High temperature	60
13.11	High temperature	60
13.12	High temperature	60
13.13	High inductance	60
13.14	Lost contact with the unit	60
13.15	Motor servo error	61
14	OPTIONAL	62
14.1	EAC 30 control unit as separate motor control	62
	ORDERING NUMBERS	65
	ACCESSORIES	66

1 INTRODUCTION

To benefit as much as possible from your welding equipment, we recommend that you read this instruction manual.


For general information about operation, see the instruction manual for the control unit, automatic welding machine, column and boom or power source.

1.1 Language

The control panel is set to English on delivery. The following languages are available: English, Swedish, Finnish, Danish, German, French, Italian, Dutch, Spanish, Portuguese, Hungarian, Polish, Czech, Norwegian, US English, Russian, Turkish, Chinese and Korean.

To select or change language, follow the instructions in section "Initial configuration".

1.2 Control panel



- | | |
|---|--|
| 1. Emergency stop | 14. Fast motion |
| 2. Currently not in use | 15. Manual travel motion |
| 3. Currently not in use | 16. Manual wire feed upwards |
| 4. Currently not in use | 17. Positioning knob, for navigating the display |
| 5. Flux valve Open / Close | 18. Home menu |
| 6. Flux recovery ON/ OFF | 19. Back |
| 7. Soft keys | 20. Signal lamp for joint-tracking |
| 8. Welding current / Wire feed speed / Setting knob | 21. Joint tracking mode |
| 9. Arc voltage / Setting knob | 22. Switch between functions |
| 10. Travel speed / Setting knob | 23. Welding stop |
| 11. Manual travel motion | 24. Welding start |
| 12. Switch between functions | 25. Motion control joystick |
| 13. Manual wire feed downwards | |

1.3 Controls

Flux valve open / close




- Press the button once to open the flux valve.
- Press the button once again to close the flux valve.

Flux recovery ON / OFF




- Press the button to activate the flux recovery unit.
- Press the button once again to switch off the flux recovery unit.

Soft keys




Three different welding data memories per welding head can be stored in the control panel memory using the soft keys 1, 2, 3, 4 and 5. The soft keys have also varying functions depending on which menu currently is in use. The current function can be seen from the text in the bottom row of the display.

Welding current / Wire feed speed setting knob




The welding current / wire feed speed / balance knob is used for increasing or decreasing set values.

Arc voltage setting knob




The arc voltage / offset voltage knob is used for increasing or decreasing set values.

Travel speed setting knob



The travel speed / frequency knob is used for increasing or decreasing set values.

Manual travel motion buttons



The buttons are used for manual travel motions.

Square travel motion



Press the square travel motion button to drive in the direction of welding where the symbol is indicated on the weld equipment.

Triangle travel motion



Press the triangle travel motion button to drive in the direction of welding where the symbol is indicated on the weld equipment.

Wire feed downwards



Press the wire feed downwards button to feed the wire downwards. The wire is fed as long as the button is pressed.

Wire feed upwards



Press the manual wire feed downwards button to feed the wire downwards. The wire is fed as long as the button is pressed.

Fast motion



The fast motion button is used together with other buttons to increase speed.

Press the button to activate fast motion and then press the manual wire feed or travel motion button. The LED on the fast motion button is lit while fast motion is activated. Press again to deactivate fast motion. During configuration, it is possible to confirm and save a value and return to previous screen using the Fast motion button.

Switch between functions



Press the switch button to select different function. The available functions are:

- Travel mode for carriage
- Travel mode for boom
- External axis

Positioning knob, for moving cursor



The right-hand knob is the positioning knob and is used to navigate menus. Press the knob to confirm a selection.

Home menu



Press the home menu button to enter the home menu.

Back button



The Back button is used to go back one step into the menu. To set wire type and wire dimension, press and hold for more than 3 seconds.

Joint tracking mode



Press the button to activate joint tracking mode.

Press the button to activate joint-tracking mode. The LED on the Joint tracking mode button is lit while joint-tracking is activated. Press again to deactivate joint-tracking.

Signal lamp



Illuminates when the guide finger is outside the working range (vertical). The automatic function is then blocked.

Welding stop




Welding stop. Stops all travel motions, all motors and welding current.

Welding start



Welding start. The LED is lit when welding is in progress.

Motion control joystick and switch button



There are three different functions for the motion control joystick. Press the switch button to switch between them.

- Use the joystick to control the movement of the boom in the triangle and square directions.
- Use the joystick to control the movement of the servo slides up/down and left/right.
- Use the joystick to control the movement of the boom up and down and to rotate the boom.

1.4 First steps

1.4.1 Display

SAW				
PROCESS			SAW	
METHOD			DC	
REGULATION TYPE			CA	
WIRE TYPE			FE SOLID	
WIRE DIMENSION			0.8 mm	
CONFIGURATION▶				
TOOLS▶				
SET	MEASURE	MEMORY	FAST MODE	

Navigating the display

To navigate the display, use the positioning knob on the right-hand side of the display. Turn the knob to navigate the menus and press the knob to confirm a selection.

Cursor

The control panel's cursor is presented as a black field around the text, with the selected text turning white.


Text boxes

At the bottom of the display are five boxes containing text that describes the current function of the five soft keys below the display.

Arrows

Where there is more information behind a row, this is indicated with a black arrow ▶ behind the text.

Symbols in the display



1. The active weld data setting
2. Welding direction
3. A fault has occurred, see event log

4. Recalled memory position number
5. Scroll bar

1.4.2 Select language

The control panel is set to English on delivery. To select your language, proceed as follows:

Press the home menu button to access the main menu, and position the cursor on the *CONFIGURATION* row, using the positioning knob.

SAW				
PROCESS			SAW	
METHOD			DC	
REGULATION TYPE			CA	
WIRE TYPE			Fe SOLID	
WIRE DIMENSION			3.0 mm	
CONFIGURATION ►				
TOOLS ►				
SET	MEASURE	MEMORY	FAST MODE	

Press the positioning knob to confirm the selection.

Position the cursor on the *LANGUAGE* row. Press the positioning knob to bring up a list of the languages that are available in the control panel.

CONFIGURATION			!	
LANGUAGE			ENGLISH	
CODE LOCK ►				
GENERAL CONFIGURATION ►				
MACHINE CONFIGURATION ►				
CABLE LENGTHS ►				
MAINTENANCE ►				
MEASURE-VALUES FILTER FACTOR			ONE	

Position the cursor on the row for your language and press the positioning knob.

NORSK	
POLSKI	
PORTUGUES	
SUOMI	
SVENSKA	
CHINESE	

1.4.3 Unit of measurements

The control panel is set to metric measurement on delivery. To change measurement unit, proceed as follows:

Press the home menu button to access the main menu, and position the cursor on the *CONFIGURATION* row, using the positioning knob.

1 INTRODUCTION

SAW				
PROCESS			SAW	
METHOD			DC	
REGULATION TYPE			CA	
WIRE TYPE			Fe SOLID	
WIRE DIMENSION			3.0 mm	
CONFIGURATION▶				
TOOLS▶				
SET	MEASURE	MEMORY	FAST MODE	

Press the positioning knob to confirm the selection.

Position the cursor on the *GENERAL CONFIGURATION* row.

CONFIGURATION				
LANGUAGE			ENGLISH	
CODE LOCK				
GENERAL CONFIGURATION▶				
MACHINE CONFIGURATION▶				
CABLE LENGTHS▶				
MAINTENACE▶				
MEASURE-VALUES FILTER FACTOR			ONE	

Press the positioning knob to confirm the selection.

Position the cursor on the *UNIT OF LENGTH* row. Press the positioning knob to bring up a list of the measurements that are available in the control panel.

GENERAL CONFIGURATION				
FAST MODE SOFT BUTTONS			1	
QUALITY DATA LOG TO FILE			ON	
SOFT KEYS SETUP▶				
AUTO SAVE MODE			OFF	
UNIT OF LENGTH			METRIC	

Position the cursor on the row for the correct measurement and press the positioning knob.

METRIC
INCH.

2 TECHNICAL DATA

Enclosure class	IP23
Operating temperature	-10 to +40 °C (+14 to 104 °F)
Transport temperature	-25 to +55 °C (-13 to 131 °F)
Relative humidity	Max 95%
Dimensions l × w × h	315 × 287 × 160 mm (12.4 × 11.3 × 6.3 in.)
Weight	2.1 kg (4.6 lbs)
Functions	
• Motion control of	Boom up/down, column turning, carriage forward/backward, slides up/down/sideways
• Setting of	Welding speed, voltage, current, wire feed speed
• Start/stop of	Welding process
• Configurable push buttons	
• Joint tracking enabled	Prepared for GMH
• Display	Monochrome

Enclosure class

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.

3 MENU

3.1 Menus

The control panel uses several different menus. Navigate the menus using the Positioning Knob, the Home menu and Back buttons, and the Soft Keys.

- Main menu
- Configuration menu
- Tools menu
- Weld data settings menu *SET*
- Measurements menu *MEASURE*
- Weld data memory menu *MEMORY*
- Fast mode menu *FAST MODE*

3.2 Home menu

In the *HOME MENU (MAIN MENU)*, you can change welding process, method, wire type, control method, wire dimension etc.

You can access other sub menus from this menu.

SAW				
PROCESS		SAW		
METHOD		DC		
REGULATION TYPE		CA		
WIRE TYPE		Fe SOLID		
WIRE DIMENSION		3.0 mm		
CONFIGURATION▶				
TOOLS▶				
SET	MEASURE	MEMORY	FAST MODE	

3.3 Configuration menu

MAIN MENU » CONFIGURATION

In the *CONFIGURATION* menu it is possible to change language, change password, make general configurations, make machine adjustments etc.

CONFIGURATION		
LANGUAGE	ENGLISH	
CODE LOCK▶		
GENERAL CONFIGURATION▶		
MACHINE CONFIGURATION▶		
MAINTENANCE▶		
NETWORK SETTINGS		
MEASURE-VALUES FILTER FACTOR	TWO	

3.4 Tools menu

MAIN MENU » TOOLS

In the *TOOLS* menu it is possible to transfer files, view quality and production statistics, event logs, etc.

TOOLS	
EVENT HANDLING▶	
EXPORT / IMPORT▶	
FILE MANAGER▶	
PRODUCT STATISTICS▶	
QUALITY FUNCTIONS▶	
CALENDAR▶	
USER ACCOUNTS▶	
UNIT INFORMATION▶	

3.5 Weld setting menu

MAIN MENU » SET

In the weld data setting menu, *SET*, it is possible to change different welding parameters. The menu has different appearances depending on which welding process is selected.

An example of the menu:

SAW WELD DATA SETTING	
VOLTAGE	24.0 V
CURRENT	3200 A
TRAVEL SPEED	30 cm/min
DIRECTION	■
AC FREQUENCY	50 HZ
AC BALANCE	50%
AC OFFSET	0 V
START DATA▶	
STOP DATA▶	OFF
REGULATION PAR.▶	OFF
SETTING LIMITS▶	OFF
MEASURE LIMITS▶	OFF
STEP FUNCTION▶	OFF
INTERMITTENT WELDING▶	
GMH JOINT TRACKING▶	

3.6 Measurement menu

MAIN MENU » MEASURE

In the *MEASURE* menu, you can view measured values for various welding parameters while welding is in progress.

SAW: CA				
EXT. AXIS	DIR. SQUARE	NONE	SET VALUES	2ND FUNCT

- **A** - Measured welding current
- **V** - Measured arc voltage
- **cm/min** - Measured travel speed
- **kJ/mm** - Shows heat input
- **kg/h** - Shows deposition rate

3.7 Memory menu

MAIN MENU » MEMORY

In the *WELD DATA MEMORY* menu you can store, recall, delete and copy various set weld data. The weld data sets can be stored in 255 different memory positions.

WELD DATA MEMORY				
1 (SAW)				
7 (GMAW)				
STORE			2ND FUNCT	

3.8 Fast mode menu

MAIN MENU » FAST MODE

In the *FAST MODE* menu, you can link soft keys to weld data memory positions. These settings are carried out in the *CONFIGURATION* menu. The number of the selected memory position is displayed in the top right corner.

16				
WELD DATA 1	WELD DATA 2	WELD DATA 3	WELD DATA 4	2ND FUNCT

4 SUBMERGED ARC WELDING (SAW)

MAIN MENU » PROCESS

During Submerged Arc Welding (SAW), an arc melts a continuously supplied wire. The weld pool is protected by flux.

When the *SAW* process is selected, choose *METHOD* with the positioning knob and press the positioning knob. Choose *AC* or *DC*.

SAW				I
PROCESS		SAW		
METHOD		AC		
REGULATION TYPE		CC		
WIRE TYPE		Fe SOLID		
WIRE DIMENSION		0.8 mm		
CONFIGURATION ▶				
TOOLS ▶				
SET	MEASURE	MEMORY	FAST MODE	

When the *SAW* process is selected, you can choose between three control methods by marking *REGULATION TYPE* using the positioning knob and pressing the knob. Choose between constant welding current CA or constant wire feed CW or constant current CC.

5 GAS METAL ARC WELDING (GMAW)

The process is available for certain machine types.

MAIN MENU » PROCESS

During Gas Metal Arc Welding (GMAW), an arc melts a continuously supplied wire. The weld pool is protected by shielding gas.

When the Gas Metal Arc Welding *GMAW* process is selected, you can choose between two control methods by marking *REGULATION TYPE* using the positioning knob and pressing the positioning knob. Choose between constant amperage *CA* or constant wire feed *CW*, see explanation in "CA, constant amperage" and "CW, constant wire feed".

<i>GMAW</i>		!	
<i>PROCESS</i>		<i>GMAW</i>	
<i>REGULATION TYPE</i>		<i>CA</i>	
<i>WIRE TYPE</i>		<i>Fe SOLID</i>	
<i>WIRE DIMENSION</i>		<i>0.8 mm</i>	
<i>CONFIGURATION ▶</i>			
<i>TOOLS ▶</i>			

6 GOUGING


Availability depending on connected equipment.

MAIN MENU » PROCESS

With arc gouging, a special electrode comprising a carbon rod with a copper casing is used.

An arc is formed between the carbon rod and the work piece, which melts the material. Air is supplied so that the melted material is blown away.

When the *GOUGING* process is selected, it is possible to choose between control methods by marking *REGULATION TYPE* using the positioning knob and pressing the knob. Choose between constant amperage *CA*, constant wire feed *CW* or constant current *CC*. For *GOUGING MODE* it is possible to choose between *AUTO* and *N7500*.

<i>GOUGING</i>		
<i>PROCESS</i>	<i>GOUGING</i>	
<i>METHOD</i>	<i>DC</i>	
<i>REGULATION TYPE</i>	<i>CW</i>	
<i>WIRE DIMENSION</i>	<i>8.0 mm</i>	
<i>GOUGING MODE</i>	<i>N7500</i>	
<i>CONFIGURATION ▶</i>		
<i>TOOLS ▶</i>		

7 ELECTRO SLAG WELDING

MAIN MENU » PROCESS

Electro slag welding (ESW) is a single pass welding process.

ESW				!
PROCESS		ESW		
METHOD		AC		
REGULATION TYPE		CA		
WIRE TYPE		SS Strip		
WIRE DIMENSION		30×0,5 mm		
CONFIGURATION▶				
TOOLS▶				
SET	MEASURE	MEMORY	FAST MODE	

8 JOINT-TRACKING

<i>GMH JOINT TRACKING</i>				
<i>JOINT TRACKING MODE</i>			<i>Manual</i>	
<i>JOINT TRACKING</i>			<i>Slide</i>	
<i>CHANGE DIRECTION</i>			<i>"<---"</i>	

JOINT TRACKING MODE *Manual, UpDown, UpDownLeft, UpDownRight or UpDownLeftRight*
Joint-tracking and joint-searching options

JOINT TRACKING *Slide or Travel*
Select if the joint-tracking should be done using the slide motor or the motor of the boom

CHANGE DIRECTION *"<---" or "--->"*
For switching the horizontal slide motor's direction of movement

Joint-tracking and joint-searching options

Manual Manual preset where the servo slide is controlled with the motion control joystick

UpDown Vertical joint-tracking

UpDownLeft Vertical and horizontal joint-tracking with joint-searching to the left


UpDownRight Vertical and horizontal joint-tracking with joint-searching to the right

UpDownLeftRight Vertical and horizontal joint-tracking

The joint-tracking equipment can be set for different types of joint-tracking. It can be set for joint-tracking with edge control and for joint-tracking with groove control. The setting is made both on the control unit and on the sensor.

8.1 Joint-tracking with edge control


The following functions are set on the control unit, *vertical and horizontal joint-tracking with joint-searching to the right* or *vertical and horizontal joint-tracking with joint-searching to the left* depending on whether right or left-hand control is required. The two stop screws on the sensor must be screwed in to the stop point. See the illustration below. This means that the fuses are spring-loaded laterally and edge control is allowed. Joint-tracking with edge control is used for welding fillet welds and similar joints, see also the joint table.



The stop screws are tightened to the stop point.

8.2 Joint-tracking with groove control







The following functions are set on the control unit, *vertical and horizontal joint-tracking* or *vertical joint-tracking* depending on whether both vertical and lateral control or just vertical control are required. The stop screws on the sensor must be screwed out at least two turns or to the stop point, see the illustration below. This releases the spring loading for the search fingers laterally and enables groove control. If the stop screws are not screwed out then there is a risk that the search fingers start to "climb" up the joint walls in shallow V and U-joints.











The stop screws screwed out 2 turns

8.3 Joint table

Examples of different types of joint and of the guide finger's application against the guiding edges.

	Joint type	Setting, control box
Double flanged butt weld		<i>UpDownLeft</i> or <i>UpDownRight</i>
I-weld (A=guide bar)		<i>UpDownLeft</i> or <i>UpDownRight</i>
V-weld		<i>UpDownLeftRight</i>
1/2 V-weld		<i>UpDownLeftRight</i>
1/2 V-weld		<i>UpDownLeft</i> or <i>UpDownRight</i>
U-weld		<i>UpDownLeftRight</i>

	Joint type	Setting, control box
Double U-weld		<i>UpDownLeftRight</i>
J-weld		<i>UpDownLeftRight</i>
Double J-weld		<i>UpDownLeftRight</i>
X-weld		<i>UpDownLeftRight</i>
Asymmetrical X-weld		<i>UpDownLeftRight</i>
K-weld		<i>UpDownLeftRight</i>
K-weld		<i>UpDownLeft or UpDownRight</i>
Fillet weld		<i>UpDownLeft or UpDownRight</i>


8.4 Position for welding start

- 1) Align the welding equipment into position in relation to the weld joint so that the working range of the slide cross covers the whole height and lateral deviation of the joint from starting point to the stopping point for welding.
- 2) Select the required *JOINT-TRACKING MODE* on the control unit.
- 3) Operate the guide finger horizontally using the motion control joystick on the control unit, until the finger is above a suitable start position, see the illustration below.

For *UpDown* joint-tracking alone the guide finger is positioned where the start of the weld is required to be.

- 4) Operate the welding head downwards with the motion control joystick, until the signal lamp goes out.

The equipment will search for the ideal position for itself vertically and horizontally if *UpDownLeft*, *UpDownRight* or *UpDownLeftRight* joint-tracking is activated.



8.5 Positioning for welding start (with inductive joint-tracking)

The product must be configured before inductive joint-tracking is possible. Contact authorised ESAB service personnel for configuration.

- 1) Align the welding equipment into position in relation to the weld joint so that the working range of the slide cross covers the whole height and lateral deviation of the joint from starting point to the stopping point for welding.
- 2) Select the *UpDown* joint-tracking option on the control unit.
- 3) Position the sensor downwards with the motion control joystick on the control unit, until the signal lamp goes out. The equipment now searches for the ideal position itself vertically.



NOTE!

If only *UpDown* joint-tracking is used, skip the following steps.

- 4) Select the *UpDownRight* mode on the control unit.
- 5) Position the sensor using the motion control joystick horizontally to the ideal position until the signal lamp goes out.
- 6) The signal lamp goes out. The equipment start to search for the ideal position itself horizontally and vertically. If the signal lamp does not go out, repeat the procedure from step 1.
- 7) For fine adjustment of the welding head position, use the slide cross for the sensor.

9 FUNCTION EXPLANATIONS

9.1 CA, constant amperage

The wire feed is controlled by the power source so that a constant amperage can be achieved.

- Constant amperage value can be selected in the main menu.

9.2 CW, constant wire feed

The welding current is a result of the selected wire feed speed.

- Constant wire feed value can be selected in the main menu.

9.3 CC, constant current

(applies only to Aristo® 1000 power source)

The voltage is varied so that a constant welding current can be achieved.

- Constant current value can be selected in the main menu.

A higher wire speed gives a higher welding current.

9.4 Wire / electrode dimension

Selected dimensions have a great impact on the start procedure and crater filling. When welding with other wire dimensions other than those found in the table, select one that has a dimension close to one in the list.

- Wire / electrode dimension can be selected in the main menu. The available wire material and dimension are affected by the combination of power source and welding head.

9.5 Arc voltage

Higher arc voltage increases the arc length and produces a hotter, wider weld pool.

- The arc voltage is set in the measurement display, weld data setting menu, or fast mode menu.

9.6 Wire feed speed

This sets the required feed speed of the filler wire in cm/minute or inch/minute. A higher wire speed gives a higher welding current.

- The wire feed speed is set in the measurement display, weld data setting menu, or fast mode menu.

9.7 ICE wire feed speed

ICE wire feed speed is used to set the percentage of the ICE wire of the hot wire speed.

- The ICE feed speed is set in the measurement display, weld data setting menu, or fast mode menu.

9.8 ICE wire start delay

ICE wire start delay is used to indicate how long (s) after welding start ICE wire feed will start.

- ICE wire start delay is set in the weld data setting menu.

9.9 Travel speed

Travel speed indicates the required speed (cm/minute or inch/minute) at which a column and boom or trolley is to move.

- The travel speed is set in the measurement display, weld data setting menu, or fast mode menu.

9.10 Welding direction

Travel motion in the direction that the symbol indicates.

- Welding direction is selected in the weld data setting menu.

9.11 AC frequency

(applies only to Aristo® 1000 power source)

AC frequency refers to the number of oscillations per second through the zero level.

- AC frequency is selected in the weld data setting menu.

9.12 AC balance

(applies only to Aristo® 1000 power source)

AC balance is the relationship between positive (+) and negative (-) pulses. The value that is set indicates the percentage size of the period that is the positive section.

- AC balance is selected in the weld data setting menu.

9.13 AC offset

(applies only to Aristo® 1000 power source)

With AC offset the AC level is offset positively or negatively in relation to the zero level.

- AC offset is selected in the weld data setting menu.

9.14 Flux pre-flow (SAW)

This controls the time during which flux flows before the arc is struck.

- Flux pre-flow is set in the weld data setting menu under start data.

9.15 Gas pre-flow (GMAW)

This controls the time during which shielding gas flows before the arc is struck.

- Gas pre-flow is set in the weld data setting menu under start data.

9.16 Start adjust

This is used to adjust the starting wire speed values. If the equipment starts with lower or higher wire speed values, compared with equipment's factory values, they can be adjusted here.

- Start adjust is set in the weld data setting menu under start data.

9.17 Air pre-flow (Gouging)

This controls the time during which air flows before the arc is struck.

- Air pre-flow is set in the weld data setting menu under start data.

9.18 Start type

There are two options for start type:

- Direct start, means that the travel speed starts when the arc is struck.
- Scratch start, means that the travel speed starts at the same time as wire feed.

Start type is selected in the weld data setting menu under start data.

9.19 Wire creep start

Wire creep start is used to set the desired creep speed on the electrode motor upon start-up.

If, for example, 50 is set in the menu a creep speed of 50 cm/min is obtained.

Preset value "AUTO" gives a creep speed calculated from the set values.

- Wire creep speed is set in the weld data setting menu under start data.

9.20 Start phases

When welding special wire or material, it may be necessary to create your own start sequence. The start sequence can affect the appearance of the weld pool.

The following can be set for Start phase1 ON

- Time s
Time for welding in phase 1.
- Arc voltage %
In percent of set voltage
- Wire feed %
In percent of set wire feed
- Welding current %
In percent of set welding current
- Travel speed %
In percent of set travel speed

The following can be set for Start phase2 ON

- Time s
Time for welding in phase 2.
- Arc voltage %
In percent of set voltage
- Wire feed %
In percent of set wire feed
- Welding current %
In percent of set welding current
- Travel speed %
In percent of set travel speed
- ICE wire speed %
In percent of live/hot wire speed

Start phases are set in the weld data setting menu under start data.

9.21 Flux post-flow (SAW)

This controls the time during which flux flows after the arc is extinguished.

- Flux post-flow is set in the weld data setting menu under stop data.

9.22 Gas post-flow (GMAW)

This controls the time during which shielding gas flows after the arc is extinguished.

- Gas post-flow is set in the weld data setting menu under stop data.

9.23 Air post-flow (Gouging)

This controls the time during which air flows after the arc is extinguished.

- Air post-flow is set in the weld data setting menu under stop data.

9.24 Crater filling

Crater filling makes a controlled reduction in the heat and size of the weld pool possible when completing the weld. This makes it easier to avoid pores, thermal cracking and crater formation in the weld joint.

- Crater filling is set in the weld data setting menu under stop data.

9.25 Burnback time

Burnback time is a delay between the time when the wire starts to brake until the time when the power source switches off the arc voltage. Too short burnback time results in a long wire stickout after completion of welding, with a risk of the wire being caught in the solidifying weld pool. Too long burnback time results in a shorter stickout, with increased risk of the arc striking back to the contact tip.

- Burnback time is set in the weld data setting menu under stop data.

9.26 Stop phases

Stop phases are mainly used for setting crater filling.

The following can be set for Stop phase1 ON

- Time s
Time for welding in phase 1.
- Arc voltage %
In percent of set voltage
- Wire feed %
In percent of set wire feed
- Welding current %
In percent of set welding current
- Travel speed %
In percent of set travel speed

The following can be set for Stop phase2 ON

- Time s
Time for welding in phase 2.
- Arc voltage %
In percent of set voltage
- Wire feed %
In percent of set wire feed
- Welding current %
In percent of set welding current
- Travel speed %
In percent of set travel speed

Stop phases are set in the weld data setting menu under stop data.

9.27 Regulation parameters

For Aristo® 1000 only, the function Control parameters is displayed instead of Dynamic control. There are two settings to make under Control parameters:

- *DYNAMICS* - Affects the dynamic characteristics
- *INDUCTANCE* - Higher values give a wider weld pool and less spatter. Lower values produce a stable, concentrated arc and a harsher sound.

Control parameters are selected in the weld data setting menu.

9.28 Setting limits

Setting limits and measured value limits are included in the welding data, so there is no need to store separate limit sets.

When you store a memory position, the setting and the measured value limits are also stored in the same memory position.

SAW WELD DATA SETTING				
WELD DIAMETER		1000 mm		
ROLL DIAMETER		1000 mm		
POLARITY		DC+		
START DATA▶				
STOP DATA▶				
REGULATION PAR.▶				
SETTING LIMITS▶		ON		
MEASURE LIMITS▶		OFF		
STEP FUNCTION▶		OFF		
INTERMITTENT WELDING▶		OFF		
MEASURE				

To activate setting limits, set *SETTING LIMITS* to *ON* and then set the desired limits.

SETTING LIMITS				
SETTING LIMITS		ON		
VOLTAGE		8.0 Volt	MIN	
VOLTAGE		60.0 Volt	MAX	
CURRENT		0 Amp	MIN	
CURRENT		4000 Amp	MAX	
WIRE FEED SPEED		0 cm/min	MIN	
WIRE FEED SPEED		3000 cm/min	MAX	
TRAVEL SPEED		0 cm/min	MIN	
TRAVEL SPEED		1000 cm/min	MAX	

To activate measured value limits, set *MEASURE LIMITS* to *ON* and then set the desired limits.

If the limits are exceeded during welding, a warning message will appear on the display, which will also be recorded in the error log.

MEASURE LIMITS				
MEASURE LIMITS			ON	
VOLTAGE			8.0 Volt	MIN
VOLTAGE			60.0 Volt	MAX
CURRENT			0 Amp	MIN
CURRENT			4000 Amp	MAX
WIRE FEED SPEED			0 cm/min	MIN
WIRE FEED SPEED			3000 cm/min	MAX
TRAVEL SPEED			0 cm/min	MIN
TRAVEL SPEED			1000 cm/min	MAX
HEAT INPUT			0.0 kJ/mm	MIN

9.29 STEP function

STEP FUNCTION				
STEP CONTROL				ON
TEST MODE				ON
TEST MODE LENGTH				0 mm
STEP DIRECTION				TRIANGLE
STEP LENGTH				76 mm
STEP SPEED				77 cm/min
NUMBER OF STEPS				10
OVERLAP				10 mm
MANUAL STEP LENGTH				3 mm
WHEEL DIAMETER				1 mm
WELD DIAMETER				1 000 mm
ROLL DIAMETER				1 000 mm

STEP CONTROL	ON or OFF On/off setting of the step function
STEP DIRECTION	SQUARE or TRIANGLE Setting of direction for the auto step execution
STEP LENGTH	The length of one auto step (minimum setting 1 mm)
STEP SPEED	The travel speed of the auto step (minimum setting 3 cm/min)
NUMBER OF STEPS	The number of steps during one rotational turn.
OVERLAP	The length of the overlap of one rotational turn.
MANUAL STEP LENGTH	The length of one manual step (minimum setting 1 mm) (for singular manual adjustments during welding)

**NOTE!**

To be able to run the step function, STEP CONTROL must be in the ON position, the EXT AXIS and AUTO STEP soft keys must be ON

If you want to have a restart of step, to restart step welding after a stop, press soft key *RESTART STEP* before you press the *AUTO STEP* before you start to weld.

For example, if you have 100 mm to next step, press *STOP*, change the wire, position the object, press *RESTART STEP*, press *AUTO STEP*, and start to weld. Next step will be after 100 mm.

When the “one turn switch” is activated, the step function executes one auto step in the direction and with the speed and length specified by the *STEP DIRECTION*, *STEP SPEED* and *STEP LENGTH* parameters.

If the FORCE STEP soft key is pushed, the step function executes one auto step in the direction and with the speed and length specified by the *STEP DIRECTION*, *STEP SPEED* and *STEP LENGTH* parameters.

If the square/triangle button is pushed, one manual step will be executed in the direction and with the speed and length specified by the square/triangle, *STEP SPEED* and *STEP LENGTH* parameters. This function can be used to make one small adjustment during welding.

There is always a possibility to interrupt an auto step or manual step movement by pushing the *SQUARE* or *TRIANGLE* button.

During the auto step or manual step movement, the LED above the square/triangle button is on to indicate movement and direction.

Speed wheel settings

When the positioner and the speed wheel are ON, the speed wheel (encoder) is at the welding object.

When the positioner and the speed wheel are OFF, the encoder is at the motor shaft.

When the roller bed and the speed wheel are ON, the speed wheel (encoder) is at the roller bed wheel.

When the roller bed and the speed wheel are OFF, the encoder is at the motor shaft.

9.30 Intermittent welding

<i>INTERMITTENT WELDING</i>	
<i>INTERMITTENT WELDING</i>	<i>ON</i>
<i>RETURN AFTER WELDING</i>	<i>ON</i>
<i>WELDING LENGTH</i>	<i>0 mm</i>
<i>TRANSPORT LENGTH</i>	<i>0 mm</i>
<i>NUMBER OF WELDS</i>	<i>0</i>

To activate the function, set intermittent welding to ON. An intermittent welding sequence consists of weld and transport. At the last weld in a sequence, the transport will not be performed.

WELDING LENGTH is the length of the weld.

RETURN AFTER WELDING after finished welding, the welding head returns to its start position.


TRANSPORT LENGTH is the length of the transport after a weld has finished.

NUMBER OF WELDS is the number of welds to be performed including transport. If the number of welds is set to “0”, the intermittent welding sequence continues until the user stops the welding using the red weld stop button.

10 MEMORY MANAGEMENT

10.1 Control panel working method

The control panel can be said to comprise two units: working memory and weld data memory.



In the working memory, a complete set of weld data settings is created that can be stored in the weld data memory.

During welding, it is always the content of the working memory that controls the process. It is therefore also possible to recall a weld data set from the weld data memory to the working memory.

Note that the working memory always contains the most recently set weld data settings. They can be recalled from the weld data memory or individually altered settings. In other words, the working memory is never empty or “zeroed”.

MAIN MENU » MEMORY » WELD DATA MEMORY

<i>WELD DATA MEMORY</i>				
<i>STORE</i>			<i>2ND FUNCT</i>	

It is possible to store up to 255 sets of weld data in the control panel. Each set is given a number from 1 to 255.

You can also delete, copy, change and name data sets and recall a set of weld data to the working memory.

10.2 Storing a set of weld data

If the weld data memory is empty, the following screen appears in the display.

Storing a set of weld data. This will be given memory position 5. Press *STORE*.

Position 1 is displayed. Turn one of the settings knobs until you reach position 5. Press *STORE*.

<i>WELD DATA MEMORY</i>				
<i>STORE</i>			<i>2ND FUNCT</i>	

The following screen appears in the display.

The weld data set is now stored as number 5.

<i>WELD DATA MEMORY</i>				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
<i>STORE</i>	<i>RECALL</i>	<i>DELETE</i>	<i>2ND FUNCT</i>	

Parts of the content of weld data set number 5 are presented at the bottom of the display.

If a data set is already stored in the selected location, you will be asked if you want to overwrite that set or not, *YES* or *NO*.

<i>WELD DATA MEMORY</i>				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
			<i>NO</i>	<i>YES</i>

<i>OVERWRITE DATA SET5 IN MEMORY?</i>

Return to the memory menu using *NO*.

10.3 Recalling a stored data set

Mark the row using the positioning knob. Press *RECALL*.



<i>WELD DATA MEMORY</i>				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
<i>STORE</i>	<i>RECALL</i>	<i>DELETE</i>	<i>2ND FUNCT</i>	

Press *YES* to confirm that you want to recall data set number 5.

WELD DATA MEMORY				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
			NO	YES

RECALL DATA SET 5 FROM MEMORY?

The icon in upper right corner of the measurement display shows which memory position number has been recalled.

SAW: FE SOLID				5
				
NONE	NONE	NONE	NONE	2ND FUNCT

10.4 Deleting data set

It is possible to delete one or more data sets in the memory menu.

Deleting a data set. Select the data set. Press *DELETE*.

WELD DATA MEMORY				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
STORE	RECALL	DELETE	2ND FUNCT	

Press *YES* to confirm that you want to delete.

WELD DATA MEMORY				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
			NO	YES

DELETE WELD DATA NR. 5?

10.5 Copying content of a weld data set to a new memory position

Press *2ND FUNCT.*

WELD DATA MEMORY				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
STORE	RECALL	DELETE	2ND FUNCT	

Select the memory position you want to copy and press *COPY*.

WELD DATA MEMORY				
5 - (SAW)				
SAW: CA: FE SOLID: 3.0 mm 30.0 V: 450 A: 50 cm/min				
COPY	RENAME	EDIT	2ND FUNCT	

We are now going to copy the content of memory position 5 to position 50.

Select memory position 1 and scroll through using one of the settings knobs to the selected memory position; in this case, position 50. Press *YES*.

<i>WELD DATA MEMORY</i>				
1 - 5 - (SAW)				
<i>COPY</i> <i>DATA SET 5 TO POSITION: 50</i>				
			NO	YES

Weld data number 5 has now been copied to memory position 50.

10.6 Naming a stored weld data set

Press *2ND FUNCT.* Select the memory position you want to rename and press *RENAME.*

<i>WELD DATA MEMORY</i>				
5 - (SAW) 50 -				
<i>SAW: CA: FE SOLID: 3.0 mm</i> <i>30.0 V: 450 A: 50 cm/min</i>				
<i>COPY</i>	<i>RENAME</i>	<i>EDIT</i>	<i>2ND FUNCT</i>	

Here you have access to a keyboard that is used as follows:


- Position the cursor on the desired keyboard character using the arrows and the positioning knob. Press *DONE.* Enter a complete text string with a maximum of 40 characters in this way.
- Press *DONE* to store. The alternative you have named can now be seen in the list.

KEYBOARD		⏏		
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9 SPACE CAPS				
0 (MAX 40)				
←	→	<i>DELETE</i>	<i>SYMBOL</i>	<i>DONE</i>


10.7 Editing content of a weld data set

Press *2ND FUNCT*. Select the memory position you want to edit and then press *EDIT*.

<i>WELD DATA MEMORY</i>				
5 - (SAW)				
<i>SAW: CA: FE SOLID: 3.0 mm</i> <i>30.0 V: 450 A: 50 cm/min</i>				
<i>STORE</i>	<i>RECALL</i>	<i>DELETE</i>	<i>2ND FUNCT</i>	

Part of the main menu is displayed and the menu shows the symbol  which means that you are in an editing mode.

Press *SET* and make the relevant changes.

<i>SAW</i>				
<i>REGULATION TYPE</i>		<i>CA</i>		
<i>WIRE TYPE</i>		<i>SS FLUX CORED</i>		
<i>WIRE DIMENSION</i>		<i>2.0 mm</i>		
<i>SET</i>				

The following menu appears:

In this example we change the welding current from 400 A to 500 A.

Select the welding current and scroll through to 500 using one of the settings knobs.

Press the back button twice.

<i>SAW WELD DATA SETTING</i>				
<i>VOLTAGE</i>		<i>20.0 V</i>		
<i>CURRENT</i>		<i>500 A</i>		
<i>TRAVEL SPEED</i>		<i>0 cm/min</i>		
<i>DIRECTION</i>				
<i>START DATA</i> ▶				
<i>STOP DATA</i> ▶				
<i>DYNAMIC REGULATION</i>		<i>AUTO</i>		
<i>SETTING LIMIT</i> ▶				
<i>MEASURE LIMITS</i> ▶				

The setting for weld data number 5 has now been edited and stored.

11 CONFIGURATION MENU

11.1 Code lock

MAIN MENU » CONFIGURATION » CODE LOCK

When the lock function is activated and you are in the measure screen or fast mode menu, a password (lock code) is required to exit from these menus.

Code lock is activated in the configuration menu.

CODE LOCK	
LOCK STATUS	OFF
SET / CHANGE LOCK CODE	-

11.1.1 Lock code status

In lock code status, you can activate/deactivate the lock function without deleting the existing lock code in the event you deactivate the function. If no lock code is stored and you try to activate the code lock, the keyboard is displayed for entering a new lock code.

KEYBOARD	!			
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9 SPACE CAPS				
0 (MAX 16)				
←	→	DELETE	SYMBOL	DONE

To exit lock status

When you are in the measure screen or the fast mode menu and the code lock is **deactivated**, you can exit these menus without restrictions by pressing the back or menu buttons in order to go to the main menu.

If it is **activated** and you try to exit, the following screen appears in order to warn the user about the lock protection.

PRESS ENTER FOR LOCK CODE...

Here you can select the back button to undo and return to the previous menu, or proceed by pressing the positioning knob to enter the lock code.

You will then move to the menu with the keyboard, where you can enter the code. Press the positioning knob after each character, and confirm the code by pressing the positioning knob again.

The following text box appears:

UNIT UNLOCKED!

If the code is not correct, an error message is displayed that offers the option of trying again or returning to the original menu, i.e. the measure screen or the fast mode menu.

If the code is correct, all blocks to other menus will be removed, **although the code lock remains activated**. This means that you can leave the measure screen and the fast mode menu temporarily, yet still retain the lock status when you return to these menus.

11.1.2 Specify/edit lock code

In specify/edit lock code, you can edit an existing lock code or enter a new one. A lock code can comprise a maximum of 16 optional letters or figures.

11.2 General configuration

11.2.1 Fast mode soft buttons

The soft keys *WELD DATA 1* up to and including *WELD DATA 4* are displayed in the fast mode menu.

<i>SAW: FE SOLID</i>				
<i>WELD DATA 1</i>	<i>WELD DATA 2</i>	<i>WELD DATA 3</i>	<i>WELD DATA 4</i>	<i>2ND FUNCT</i>

These are configured as follows:

Position the cursor on the row for *SOFT KEY NUMBER*.

<i>FAST MODE SOFT BUTTONS</i>	
<i>SOFT KEY NUMBER</i>	1
<i>ASSOCIATED WELD DATA</i>	1
<i>SAW: DC: FE SOLID: 0.8 mm</i> <i>30.0 V: 500 A: 30 cm/min</i>	
<i>STORE</i>	<i>DELETE</i>

The keys are numbered 1-4 from left to right. Select the desired key by giving its number using the setting knobs.

Then scroll to the next row *ASSOCIATED WELD DATA*. Here you can browse through the weld data sets that are stored in the weld data memory. Selected the desired weld data number using the setting knobs. Press *STORE* to save. To delete the stored set, press *DELETE*.

11.2.2 Quality data log to file

Activate *QUALITY DATA LOG TO FILE* menu by selecting *ON*.

<i>GENERAL CONFIGURATION</i>				
<i>FAST MODE SOFT BUTTONS</i>				<i>1</i>
<i>QUALITY DATA LOG TO FILE</i>				<i>ON</i>
<i>SOFT KEYS SETUP ▶</i>				
<i>AUTO SAVE MODE</i>				<i>OFF</i>
<i>UNIT OF LENGTH</i>				<i>METRIC</i>

The file is in a folder called QData is created automatically when you insert a USB memory.

Read more about settings for the quality function in section "Quality functions".

11.2.3 Soft key configuration

For Submerged Arc Welding (SAW) and for Gas Metal Arc Welding (GMAW) welding, the user has the possibility of setting the function of these keys by selecting from a list of set options. There are eight soft keys that can be allocated a function.

It is possible to choose between the following options:

- None
- Gas / Flux
- Set values
Set reference values are displayed instead of the measured values in the measurements menu.
- Relay 2
Sets relay output no.2 on the motor circuit board, which can be used for any function by the customer.
- Direction
- Remote I/O
Used when you want to control EAC 30 and a welding power source via an external I/O unit.
- External axis
To be activated when there is an external I/O unit for controlling a roller bed, for example.
- Tandem
Used when welding with two welding heads.
- ICE WF
Used when a non-live wire is fed into the weld pool and the ICE wire speed is to be shown in the display.
- Auto step
Used in the step function
 - Auto step Off: Setting during preparation of the object before welding
 - Auto step On: Setting after preparation is finished when welding should be executed
- Force step
Used in the step function to manually force one auto step during welding
- Stop zero pos
Used to stop automatically at the started rotation position.
- Restart
When welding is stopped with 100mm left to the start of the next step. Press restart step and the next step is after 100mm, not after Xmm. Then press the welding start key.
- A2TF J1
Product code.
- A2TG J1
Product code.

- A6TX
Product code.
- MTW600
Product code.
- USER DEF.AXIS
Product code.
- N7500i-A2
Product code.
- N7500i-A6
Product code.
- ETC
Product code.
- EWHC 1000
Product code.

In the display screen there are two columns; one for *SOFT KEYS* and one for *FUNCTION*.

<i>SOFT KEYS SETTINGS</i>	
<i>SOFT KEYS</i>	<i>FUNCTION</i>
S1	NONE
S2	NONE
S3	NONE
S4	NONE
S1 2ND FUNCT	NONE
S2 2ND FUNCT	NONE
S3 2ND FUNCT	NONE
S4 2ND FUNCT	NONE

When you allocate functions to these keys, they are numbered from the left as follows:

<i>S1</i>	<i>S2</i>	<i>S3</i>	<i>S4</i>	<i>2ND FUNCT</i>
<i>S1 2ND FUNCT</i>	<i>S2 2ND FUNCT</i>	<i>S3 2ND FUNCT</i>	<i>S4 2ND FUNCT</i>	<i>2ND FUNCT</i>

To allocate a new function to a soft key, proceed as follows:

Position the cursor on the row with the soft key number you wish to use and press the positioning knob. A pop-up menu shows the function selections. Select using the positioning knob and press the knob.

<i>SOFT KEY SETUP</i>	
<i>SOFT KEYS</i>	<i>FUNCTION</i>
S1	NONE
S2	NONE
S3	NONE
S4	NONE
S1 2ND FUNCT	NONE
S2 2ND FUNCT	NONE
S3 2ND FUNCT	NONE
S4 2ND FUNCT	NONE

NONE
FLUX
SET VALUES
RELAY 2
DIRECTION
REMOTE IO
EXT. AXIS
TANDEM
ICE WF
AUTO STEP
FORCE STEP
STOP ZERO POS
RESTART
A2TF J1
A2TG J1
A6TX
MTW600
USER DEF.AXIS
N7500i-A2
N7500i-A6
ETC
EWHC 1000

You can allocate new functions to the other keys in the same way, by pairing a key number in the left-hand column with a function in the right-hand column.

11.2.4 Auto save mode

When a weld data set has been recalled from a memory position in the weld data memory and you change the settings, the changes will be saved in the working memory at welding stop in the last recalled memory position.

Saving weld data manually in a memory position disables the next automatic save.

The memory position in which the weld data set is stored is displayed in the top right corner of the measure screen.

11.3 Machine configuration

11.3.1 Product code

In the *PRODUCT CODE* menu it is possible to select the automatic welding machine, column and boom, roller bed or positioner to be used.

<i>MACHINE CONFIGURATION</i>		
<i>PRODUCT CODE</i>		<i>A2TF J1</i>
<i>WIRE FEED AXIS 1</i> ▶		
<i>TRAVEL AXIS</i> ▶		
<i>TANDEM</i> ▶		
<i>PARALLEL POWERSOURCES</i> ▶		
<i>ICE WIRE FEED</i> ▶		<i>OFF</i>
<i>STEP FUNCTION</i> ▶		<i>OFF</i>
<i>INTERMITTENT WELDING</i>		
<i>NODE ID SETTINGS</i> ▶		<i>POSITIVE</i>
<i>SYSTEM INFORMATION</i> ▶		

When selecting product code, the correct motor type and gear ratio for the used gearbox in the relevant product are selected automatically.

The following options can be selected:

- *A2TFJ1*
A2 tractor automatic welding machine for Submerged Arc Welding (SAW)
- *A2TGJ1*
A2 tractor automatic welding machine for Gas-Shielded Metal Arc Welding (GMAW)
- *A6TFF1*
A6 tractor automatic welding machine for Submerged Arc Welding (SAW)
- *MTW600*
A6 tractor automatic welding machine for Submerged Arc Welding (SAW)
- *N7500i-A2*
Welding head for Gouging, A2 tractor.
- *N7500i-A6*
Welding head for Gouging, A6 tractor.
- *USER DEF.AXIS*
Optional configuration for connecting external roller beds, positioners or linear axis as well as for 2 motors to the actuator board. One for wire feed and one for travel motion.
- *Motor Control*
Optional configuration to use the control unit for separate motor control without a power source.
- *EWHC 1000*

11.3.2 Wire feed axis 1

The wire feed motor is set automatically according to the tables below.

	A2TFJ1	A2TGJ1	A6TFF1
Motor	5035 38 RPM	5035 68 RPM	VEC 4000
Gear 1	49:1	49:1	156:1
Gear 2	1:1	1:1	1:1
Diameter feed rollers	49 mm	49 mm	49 mm
Pulse sensor	28 ppr	28 ppr	32 ppr
Low manual speed	150 cm/min	150 cm/min	150 cm/min
High manual speed	300 cm/min	300 cm/min	300 cm/min

	MTW600	N7500i-A2	N7500i-A6
Motor	FHP258	N7500i 10000	N7500i 10000
Gear 1	24:1	576:1	576:1
Gear 2	1:1	1:1	1:1
Diameter feed rollers	30 mm	40 mm	40 mm
Pulse sensor	28 ppr	128 ppr	128 ppr
Low manual speed	150 cm/min	61 cm/min	61 cm/min
High manual speed	300 cm/min	150 cm/min	150 cm/min

	USER DEF.AXIS	Motor Control	EWHC 1000
Motor	VEC 4000	VEC 4000	DOGA PM2719
Gear 1	156:1	156:1	52:1
Gear 2	1:1	1:1	1:1
Diameter feed rollers	49 mm	49 mm	47 mm
Pulse sensor	32 ppr	32 ppr	16 ppr
Low manual speed	150 cm/min	150 cm/min	150 cm/min
High manual speed	300 cm/min	300 cm/min	300 cm/min

11.3.3 Wire feed axis 2

	USER DEF.AXIS
Motor	VEC 4000
Gear 1	156:1
Gear 2	1:1
Diameter feed rollers	49 mm
Pulse sensor	32 ppr
Low manual speed	150 cm/min
High manual speed	300 cm/min

11.3.4 Travel axis

The travel motor is set automatically according to the tables below.

	A2TFJ1	A2TGJ1	A6TFF1
Motor	4030-350	4030-350	FHP258
Gear 1	375:10	375:10	24:1
Gear 2	51:1	51:1	51:1
Wheel diameter	158 mm	158 mm	180 mm
Pulse sensor	60 ppr	60 ppr	28 ppr
High manual speed	200 cm/min	200 cm/min	200 cm/min

	MTW600	N7500i-A2	N7500i-A6
Motor	A2 4030-350	A2 4030-350	A2 5035-751
Gear 1	75:2	75:2	24:1
Gear 2	51:1	51:1	51:1
Wheel diameter	158 mm	158 mm	180 mm
Pulse sensor	60 ppr	60 ppr	28 ppr
High manual speed	200 cm/min	200 cm/min	200 cm/min

	USER DEF.AXIS	Motor Control	EWHC 1000
Motor	VEC 4000	VEC 4000	VEC 4000
Gear 1	312:1	312:1	312:1
Gear 2	1:1	1:1	1:1
Wheel diameter	65 mm	65 mm	65 mm
Pulse sensor	32 ppr	32 ppr	32 ppr
High manual speed	200 cm/min	200 cm/min	200 cm/min

11.3.5 External axis

When connecting an external roller bed, positioner or linear axis, *USER DEF.AXIS* must be selected.

When *USER DEF.AXIS* is selected, the motor is automatically set according to the tables below.

	Roller bed	Linear	Positioner
Gear 1	560:1	560:1	560:1
Gear 2	111:22	111:22	111:22
Gear 3	1:1	1:1	1:1
Wheel diameter	160 mm	160 mm	160 mm
Pulse sensor	30 ppr	30 ppr	30 ppr
High manual speed	200 cm/min	200 cm/min	200 cm/min
Frequency ratio	85:50	85:50	85:50
Motor	2000 rpm	2000 rpm	2000 rpm
Weld diameter	1000 mm	-	1000 mm
Roller diameter	1000 mm	-	-

When the positioner and the speed wheel are ON, the speed wheel (encoder) is at the welding object.

When the positioner and the speed wheel are OFF, the speed wheel (encoder) is at the motor shaft.

When the roller bed and the speed wheel are ON, the speed wheel (encoder) is at the roller bed wheel.

When the roller bed and the speed wheel are OFF, the speed wheel (encoder) is at the motor shaft.

11.3.6 Tandem

Used when welding with two or more welding heads. The welding heads are each controlled by their own control unit.

Position the cursor on the *TANDEM* row and press the positioning knob. Select *ON* using the positioning knob and press the knob.

The front welding head is selected.

<i>TANDEM</i>				
<i>AC SYNC MASTER</i>				<i>ON</i>
<i>PHASE SHIFT</i>				
<i>TRAVEL CONTROL</i>				<i>ON</i>
<i>TANDEM</i>				<i>ON</i>
<i>L WELDING HEAD</i>				<i>HEAD</i>
<i>L SYNCRONIZED WELD START</i>				<i>ON</i>

The rear welding head is selected.

<i>TANDEM</i>				
<i>AC SYNC MASTER</i>				<i>OFF</i>
<i>L PHASE SHIFT</i>				<i>90</i>
<i>TRAVEL CONTROL</i>				<i>OFF</i>
<i>TANDEM</i>				<i>ON</i>
<i>L WELDING HEAD</i>				<i>TAIL</i>
<i>L SYNCRONIZED WELD START</i>				<i>ON</i>
<i>L WELD HEAD OFFSET</i>				<i>20 mm</i>

WELDING HEAD

Select whether the welding head is to be the front *HEAD* or rear *TAIL*.

AC SYNC MASTER

If more than one AC power source is in the tandem set-up, then one of them (preferably the first of them) has to be assigned *AC SYNC MASTER*.

TRAVEL CONTROL

Select whether the welding head is controlling the travel. Both the front and rear welding heads can control the travel, but only one at a time.


SYNCRONIZED WELD START

If ON is selected it means that one only need start the control unit for the front welding head. The rear one is started automatically. If OFF is selected all the welding heads must be started using the relevant control unit.

NOTE!
Synchronized AC welding is always ON at AC welding, meaning that the frequency and balance of the AC pulses are synchronized to the same values for all welding heads in the tandem system.

WELD HEAD OFFSET

WELD HEAD OFFSET is the distance in millimetres between the welding heads. The weld head offset should always be set, whether a synchronised welding start is selected or not. If a **non**-synchronised welding start is selected, the offset is used to calculate a time delay for the welding start on the **TAIL** welding head.



- 1. HEAD, Welding head 1 (master)
- 2. TAIL, welding head 2 (slave)
- 3. WELD HEAD OFFSET

PHASE SHIFT (applies only to AC welding)

Phase shift means a phase offset in relation to the front welding head. The unit is degrees.

11.3.7 Parallel power sources

To be able to set up power sources in parallel, only the power sources that are to be connected should have power on and be active on the CAN2 bus.

<i>PARALLEL POWERSOURCES</i>	
<i>PARALLEL POWERSOURCES</i>	<i>OFF</i>
<i>Number of power sources</i>	<i>2</i>
<i>Parallel couple ID</i>	<i>1</i>
<i>Parallel status</i>	<i>--</i>

Number of power sources

How many power sources we have in parallel.

Parallel couple id

Identification id for the active couple of parallel power sources. If you have a second couple of parallel power sources in a tandem system, they must have a unique id number.

Parallel status

Indicates if the power sources are parallelly connected or not.

<i>PARALLEL POWERSOURCES</i>				
<i>PARALLEL POWERSOURCES</i>				<i>ON</i>
<i>Number of power sources</i>				<i>2</i>
<i>Parallel couple ID</i>				<i>1</i>
<i>Parallel status</i>				<i>--</i>

Perform settings for parallel power sources as follows:

1. Set the *PARALLEL POWERSOURCES* function to *ON*.
2. Set *Number of power sources*.
3. Set *Parallel couple ID*. The first parallel couple is set to 1, the next parallel couple is set to 2 etc.
4. Press soft button *Connect*.
5. When the master and slave power sources are connected, the text *Connected* is presented as *Parallel status*.

Indication will also be in the measurement view, in the status field. The symbol || will be shown if the master has detected the specified slave units.

11.3.8 ICE wire feed



NOTE!

ICE option is only available with an ICE license. Contact ESAB for more information.

The option *ICE WIRE FEED ON* can be selected in the machine configuration menu. If ICE wire feed is selected, the option *WIREFEED AXIS 2* appears.

<i>MACHINE CONFIGURATION</i>				
<i>PRODUCT CODE</i>				<i>USER DEF.AXIS</i>
<i>WIREFEED AXIS 1▶</i>				
<i>WIREFEED AXIS 2▶</i>				
<i>TRAVEL AXIS▶</i>				
<i>EXTERNAL AXIS▶</i>				
<i>TANDEM▶</i>				
<i>PARALLEL POWERSOURCES▶</i>				
<i>ICE WIRE FEED</i>				<i>ON</i>
<i>NODE ID SETTINGS▶</i>				
<i>SYSTEM INFORMATION▶</i>				

WIREFEED AXIS 2	
MOTOR	VEC4000
GEAR 1▶	ON
L N 1	74
L N 2	1
GEAR 2▶	ON
L N 1	1
L N 2	1
FEED ROLLER DIAM	49 mm
ENCODER PULSES	32 ppr
LOW MANUAL SPEED	150 cm/min

Motor is selected from a dropdown list with the following options:

5035 38RPM
5035 68RPM
FHP258
VEC8000
VEC4000
DUNKER1
DUNKER2
MET3B
VEC4000Par
A2 4030-350

- *GEAR 1* must be set to *ON*. The value cannot be *OFF*.
- *GEAR 2* must normally be set to *ON*, but *OFF* can be selected.
- The values *N1* and *N2* under *GEAR 1* and *GEAR 2* are set with one of the three settings knobs at the bottom of the panel. The interval for N1 and N2 depend on selected motor.
- The diameter of the feed rollers *FEED ROLLER DIAM* is selected with any settings knob. The interval depends on selected motor.
- The encoder for pulses *ENCODER-PULSES* is selected with any settings knob. The interval is between 1 - 9998 ppr (ppr = pulses per revolution).
- *LOW MANUAL SPEED* is selected with any of the settings knobs.
- *HIGH MANUAL SPEED* is selected with any of the settings knobs.

11.3.9 Node id settings

If there are I/O nodes in the system the ID numbers are given here.

NODE ID SETTINGS	
I/O NODE 1 ID	17
I/O NODE 2 ID	25

11.3.10 System information

The *SYSTEM INFORMATION* menu shows active power sources connected via the CAN2 bus, if the power sources are in tandem or parallel mode and if they are configured as master or slave.

<i>SYSTEM INFORMATION</i>				
<i>Active power sources on CAN2</i>				
<i>PS id</i>		<i>Tandem</i>	<i>Parallel</i>	
<i>No contact with master power source</i>				

11.4 Maintenance

MAIN MENU » CONFIGURATION » MAINTENANCE

In this menu you set how often the contact tip is to be changed. Specify the number of weld starts after which the tip is to be changed by selecting the *CONTACT TIP CHANGE INTERVAL* row and pressing the positioning knob. Change the value using the setting knobs. When the interval has been passed, fault code 54 is displayed in the error log.

When *TOTAL RUNNING TIME LIMIT* is selected instead of the number of starts, an authorised ESAB service technician is contacted.

<i>MAINTENANCE</i>				
<i>CONTACT TIP CHANGE INTERVAL</i>				<i>0 Welds</i>
<i>L WELD COUNT</i>				<i>0 Welds</i>
<i>TOTAL RUNNING TIME LIMIT</i>				<i>0d:00:00:00</i>
<i>L TOTAL RUNNING TIME</i>				<i>0d:00:00:00</i>

11.5 Network settings

Settings for connection to WeldCloud™ gateway.

<i>NETWORKS SETTINGS</i>				
<i>DHCP</i>				<i>OFF</i>
<i>IP ADDRESS</i>				<i>0.0.0.0</i>
<i>WELDING HEAD ID</i>				<i>1</i>
<i>TORCH ID</i>				<i>1</i>

DHCP

Set DHCP to OFF.

IP ADDRESS

In a tandem system for the first control unit, set the 192.168.0.100 IP address. For the following unit, set 192.168.0.101.

WELDING HEAD ID

An identifier for the welding head. All control units connected to the welding head will have the same identifier.

TORCH ID

Torch id is the number in the transport direction that the welding electrodes have in a tandem system.

11.6 Measure-values filter factor*MAIN MENU » CONFIGURATION » MEASURE-VALUES FILTER FACTOR*

This menu provides a filter factor for the measurement values of the welding current. The higher filter factor value you choose, the more stable welding current measurement value you will get. You can choose between filter factors 1, 2 and 4.

Position the cursor on the *MEASURE-VALUES FILTER FACTOR* row and press the positioning knob. A pop-up menu shows filter factors *ONE*, *TWO* and *FOUR*. Select the preferred filter factor using the positioning knob and press the knob.

<i>CONFIGURATION</i>				□
<i>LANGUAGE</i>				<i>ENGLISH</i>
<i>CODE LOCK ▶</i>				
<i>GENERAL CONFIGURATION ▶</i>				
<i>MACHINE CONFIGURATION ▶</i>				
<i>CABLE LENGTHS ▶</i>				
<i>MAINTENANCE ▶</i>				
<i>MEASURE-VALUES FILTER FACTOR</i>				<i>ONE</i>

<i>ONE</i>
<i>TWO</i>
<i>FOUR</i>

12 TOOLS MENU

12.1 Event handling

12.1.1 Event log

MAIN MENU » TOOLS » EVENT HANDLING » EVENT LOG

EVENT LOG				
<i>Index</i>	<i>Date</i>	<i>Time</i>	<i>Unit</i>	<i>Error</i>
1	180917	11:24:13	8	19
2	181021	10:15:36	8	17
<i>DELETE</i>		<i>DELETE ALL</i>	<i>UPDATE</i>	<i>VIEW TOTAL</i>

All errors that occur during the use of the welding equipment are documented as error messages in the event log.

Up to 99 error messages can be saved. If the error log becomes full, i.e. if 99 error messages have been saved, the oldest message is automatically deleted when the next error occurs.

Only the most recent error message is displayed on the control panel.

Errors are monitored/detected in two ways: by test routines that are run on initiation and by functions that can detect an error when it occurs.

Headings used in the error log:

- *Index* Error message number
- *Date* When the error occurred, in format YYMMDD
- *Time* When the error occurred, in format hh:mm:ss
- *Unit* Which unit has generated the error message
- *Error* Error code number


Unit ID for Aristo® 1000 power source:

- | | |
|-------------------------|------------------------|
| 1 = Power source | 8 = Welding data unit |
| 6 = Motor control board | 9 = Analogue I/O board |

12.1.2 Active errors

MAIN MENU » TOOLS » EVENT HANDLING » ACTIVE ERRORS

The Active errors menu shows only the errors active for the moment.

ACTIVE ERRORS		
<i>Error nr</i>	<i>Node ID</i>	<i>Device type</i>
78	1	powersource
152	1	powersource
<i>Error nr 78</i>		

12.2 Export Import

MAIN MENU » TOOLS » EXPORT / IMPORT

In the Export/Import menu, it is possible to transfer information to and from the control panel via a USB memory.

The following information can be transferred:

- *WELD DATA SETS* *EXPORT / IMPORT*
- *SYSTEM SETTINGS* *EXPORT / IMPORT*
- *EVENT LOG* *EXPORT*
- *QUALITY FUNCTION LOG* *EXPORT*
- *PRODUCTION STATISTICS* *EXPORT*
- *USER ACCOUNTS* *EXPORT / IMPORT*

Carry out the following to save on a USB memory:

Insert the USB memory into the control unit.

Select the row with the information that is to be transferred. Press *EXPORT* or *IMPORT*, depending on whether the information is to be exported or imported.

<i>EXPORT/IMPORT</i>				
<i>WELD DATA SETS</i>				
<i>SYSTEM SETTINGS</i>				
<i>SETTING LIMITS</i>				
<i>MEASURE LIMITS</i>				
<i>EVENT LOG</i>				
<i>QUALITY FUNCTION LOG</i>				
<i>PRODUCTION STATISTICS</i>				
<i>USER ACCOUNTS</i>				
<i>EXPORT</i>	<i>IMPORT</i>			

12.3 File manager

MAIN MENU » TOOLS » FILE MANAGER

In the file manager it is possible to manage information on a USB memory (C:\). File manager makes it possible to delete and copy weld data and quality data manually.

When the USB memory is connected, the display shows the memory's default folder if one is not previously selected.

The control panel remembers where you were the last time you used file manager, so that you return to the same place in the file structure when you come back.

FILE MANAGER				
..				
NEW FOLDER				
QData.xml				
INFO	UPDATE		ALT.	

- Update the information by pressing *UPDATE*.
- When you want to delete, change name, create new folder, copy or paste, press *ALT*. A list then appears from which you can choose. If (..) or a folder is selected, you can only create a new folder or paste in a file that you have previously copied. If you have selected a file, the options *RENAME*, *COPY* or *PASTE* will be added if you have previously copied a file.

FILE MANAGER				
..				
WeldData				
NEW FOLDER				
ErrorLog.xml				
QData.xml				
~Weldoffice.dat				
INFO	UPDATE		ALT.	

This list is displayed when you have pressed *ALT*.

<i>COPY</i>
<i>PASTE</i>
<i>DELETE</i>
<i>RENAME</i>
<i>NEW FOLDER</i>

If *RENAME* or *NEW FOLDER* is selected, a keyboard appears in the display. Use the positioning knob to change row and the arrows to move left and right. Select the character/function that is to be used and press the positioning knob to confirm.

KEYBOARD				
A B C D E F G H				
I J K L M N O P				
Q R S T U V W X Y Z				
0 1 2 3 4 5 6 7 8 9				
SPACE CAPS				
ErrorLog.xml				
12 (MAX 40)				
←	→	DELETE	SYMBOL	DONE

12.4 Production statistics

MAIN MENU » TOOLS » PRODUCTION STATISTICS

The production statistics will keep track of the total arc time, the total amount of material and the number of welds since the most recent reset. They will also keep track of the arc time and the amount of material used in the most recent weld. For information purposes, the melted wire material per length unit that has been calculated and when the most recent reset occurred are also displayed.

PRODUCTION STATISTICS			
		LAST WELD	TOTAL
ARCTIME		0s	0s
CONSUMED WIRE		0g	0g
CONSUMED ICE WIRE		-	-
DEPOSITION RATE		0 kg/h	
BASED ON		1g/m	0 kg/h
NUMBER OF WELDS			0
LAST RESET		081114	08:38:03
RESET	UPDATE		

When you press *RESET*, all counters are reset. Date and time show the most recent reset.

If you do not reset the counters, these are all automatically reset when one of them has reached its maximum value.

Maximum counter values

Time	999 hours, 59 minutes, 59 seconds
Weight	13350000 grams
Quantity	65535

12.5 Quality functions

MAIN MENU » TOOLS » QUALITY FUNCTIONS

Quality functions keep track of various interesting weld data for individual welds.

These functions are:

- Time of welding start.
- Duration of welding.
- Maximum, minimum and average current during welding.
- Maximum, minimum and average voltage during welding.
- Maximum, minimum and average energy per unit length during welding.

The number of welds since the most recent reset is displayed in the row at the bottom. Information can be stored about a maximum of 300 welds. In the event of more than 300 welds, the first one is overwritten.

The most recently noted weld is presented in the display, although it is also possible to browse between other noted welds. All logs are deleted when you press *RESET*.

QUALITY FUNCTIONS				
WELD: 2 - 1		TOTAL: 2		
START 20231109 10:48:14				
WELD TIME 00:00:20 WELD DATA: 2				
		MAX	MIN	AVE.
I (Amp)		285.00	239.00	265.00
U (V)		23.90	20.80	22.50
Q (kJ/min)		0.70	0.70	0.70
V(t) (cm/min)		63.60	63.60	63.60
V(w) (cm/min)		101.00	94.20	97.60
RESET	UPDATE			

Store quality data

MAIN MENU » TOOLS » EXPORT / IMPORT

The files that are produced in the control panel are stored as xml files. The USB memory must be formatted as FAT32 in order to work.

Insert a USB memory in the control panel, select *QUALITY FUNCTION LOG*, and press *EXPORT*.

EXPORT/IMPORT				
WELD DATA SETS				
SYSTEM SETTINGS				
EVENT LOG				
QUALITY FUNCTION LOG				
PRODUCTION STATISTICS				
USER ACCOUNTS				
EXPORT				

The entire set of quality data (information about the 300 most recent welds) that is stored in the control panel is now saved on the USB memory.

12.6 Calender

MAIN MENU » TOOLS » CALENDAR

Date and time are set here.

Select the row that is to be set: *YEAR*, *MONTH*, *DAY*, *HOUR*, *MINUTES* or *SECONDS*. Set the correct value using one of the setting knobs. Press *SET*.

DATE & TIME	
YEAR	2019
MONTH	NOV
DAY	21
HOUR	10
MINUTES	45
SECONDS	55
20100115	
10:48:59	
SET	

12.7 User accounts

MAIN MENU » TOOLS » USER ACCOUNTS

Occasionally it is particularly important from a quality perspective that the product cannot be used by unauthorised parties.

User name, account level and password are registered in this menu.

Select *USER NAME* and press the positioning knob. Step down to an empty row and press the knob. Enter a new user name on the keyboard using the positioning knob and the arrows.

USER ACCOUNTS	
USER NAME	ADMINISTRATOR
LACCOUNT LEVEL	ADMIN
LPASSWORD	
USER ACCOUNTS	OFF
STORE	DELETE

There is space for 16 user accounts. In the quality data files it will be evident which users have executed a particular weld.

Under *ACCOUNT LEVEL* choose from:

- | | |
|--------------------|--|
| <i>ADMIN</i> | <i>FULL ACCESS</i> (can add new users) |
| <i>SENIOR USER</i> | can access everything except: <i>MACHINE CONFIGURATION</i> , <i>USER ACCOUNTS</i> and <i>NETWORK SETTINGS</i> |
| <i>NORMAL USER</i> | can access: <i>MAINTENANCE</i> in <i>CONFIGURATION</i> menu. <i>UNIT INFORMATION</i> in <i>TOOLS</i> menu. <i>VOLTAGE</i> , <i>CURRENT / WIRE FEED</i> , <i>TRAVEL SPEED</i> and <i>WELDING DIRECTION</i> in <i>SETTINGS</i> menu. |

In the *PASSWORD* row, key in a password using the keyboard. When the power source is switched on and the control panel activated, you are asked in the display to enter your password.

If you choose not to have this function, but instead want the power source and control panel to be unlocked for all users, select *USER ACCOUNTS OFF*.

12.8 Unit information

MAIN MENU » TOOLS » UNIT INFORMATION

This menu contains the following information:

- Machine ID
- Node ID
- HW ID (Hardware ID)
- Software version
- Serial number, if available
- *INFO* is shown if the unit selected contains subunits. If the soft button is pressed then you will get a new menu with information (same fields as in the previous menu) on the subunits.

<i>UNIT INFORMATION</i>			
<i>Machine ID</i>	<i>Node ID</i>	<i>HW ID</i>	<i>Version</i>
44	8	0	5.08A
50	1	14	2.10A
5	6	1	1.40A
<i>POWER SOURCE 1</i>			
<i>Seral Number 1452226815</i>			
	<i>UPDATE</i>		<i>INFO</i>

<i>UNIT INFORMATION</i>			
<i>Machine ID</i>	<i>Node ID</i>	<i>HW ID</i>	<i>Version</i>
50	1	14	2.10A
-	-	-	0.02m
-	-	-	0.02m
<i>POWER SOURCE 1</i>		<i>DSP 1</i>	

13 ERROR CODES

6 High temperature

The power source has overheated. Welding is cancelled. Welding is permitted again when the temperature falls below the maximum temperature parameter.

1. Check that the cooling air inlets or outlets are not obstructed or clogged with dirt.
2. Check the duty cycle being used, to make sure that the equipment is not being overloaded.

7 Low welding current

The weld arc has been shut down due to too low welding current during the welding process.

1. Is reset at next weld start. If the error persists, send for a service technician.

8 Low battery voltage

Battery voltage too low. If the battery is not replaced, all stored data will be lost. This error does not disable any functions.

1. Send for a service technician to replace the battery.

11 Speed error on a motor (wire feed, travel motor)

A motor cannot maintain its speed. Welding stops.

1. Check that the wire feed has not jammed or runs too fast. If the error persists, send for a service technician.
2. If the error persists, send for a service technician.

17 Lost contact with the unit

Lost contact with a unit.

1. Check wiring and the connector between the control unit and power source.

43 High welding current

Power source have switched off the welding process because the current has exceeded the maximum current parameter for the power source.

1. Is reset at next weld start. If the error persists, send for a service technician.

44 Current servo saturation

The welding process has stopped because it has not advanced within 10 seconds.

1. Is reset at next weld start. If the error persists, send for a service technician.

2310 Current servo saturation

The power source has temporarily delivered maximum current.

1. If the error persists, try lowering the weld data.

3205 High DC voltage

1. Check if the main voltage is too low or too high.

4201 High temperature

The power source has overheated. Welding is cancelled. Welding is permitted again when the temperature falls below the maximum temperature parameter.

1. Check that the cooling air inlets or outlets are not obstructed or clogged with dirt.
2. Check the duty cycle being used, to make sure that the equipment is not being overloaded.

4202 High temperature

The power source has overheated. Welding is cancelled. Welding is permitted again when the temperature falls below the maximum temperature parameter.

1. Check that the cooling air inlets or outlets are not obstructed or clogged with dirt.
2. Check the duty cycle being used, to make sure that the equipment is not being overloaded.

4203 High temperature

The power source has overheated. Welding is cancelled. Welding is permitted again when the temperature falls below the maximum temperature parameter.

1. Check that the cooling air inlets or outlets are not obstructed or clogged with dirt.
2. Check the duty cycle being used, to make sure that the equipment is not being overloaded.

5010 High inductance

Inductance is too high, depending on long welding cables and/or high weld data.

1. Adjust the welding data.

8117 Lost contact with the unit

Lost contact with a unit.

1. Check wiring and the connector between the control unit and power source.

8411	Motor servo error
-------------	--------------------------

A motor cannot maintain its speed. Welding stops.

1. If wire motor: check that the wire feed has not jammed or runs too fast.
2. Check the motor cables.
3. If travel motor: replace the pulse transducer.
4. If the error persists, send for a service technician.

14 OPTIONAL

14.1 EAC 30 control unit as separate motor control

EAC 30 as motor control without a power source is used when you want to have a travel control and possibility to give a start signal to an external power source. Remote is also active via ATAS I/O so you can control a roller bed with relay out for the start and an analogue reference for speed.

Activate motor control

To activate the motor control function set *PRODUCT CODE* to *MOTOR CONTROL*. The supervision by the power source is now disabled.

<i>MACHINE CONFIGURATION</i>				
<i>PRODUCT CODE</i>			<i>Motor control</i>	
<i>WIRE FEED AXIS 1▶</i>				
<i>TRAVEL AXIS▶</i>				
<i>TANDEM▶</i>				
<i>PARALLEL POWERSOURCES▶</i>				
<i>ICE WIRE FEED▶</i>				<i>OFF</i>
<i>NODE ID SETTINGS▶</i>				
<i>SYSTEM INFORMATION▶</i>				

<i>A6TF F1</i>
<i>MTW600</i>
<i>N7500i-A2</i>
<i>N7500i-A6</i>
<i>USER DEF.AXIS</i>
<i>Motor control</i>

Travel axis and wire axis

Set travel axis and wire gearing by performing the same procedure as for product code external axis.

Setting menu

Here you can set travel speed and direction, start data and limits can be used for travel speed.

<i>SAW WELD DATA SETTING</i>				
<i>TRAVEL SPEED</i>			<i>30 cm/min</i>	
<i>DIRECTION</i>				
<i>START DATA▶</i>				■
<i>SETTING LIMITS▶</i>				
<i>MEASURE LIMITS▶</i>				
<i>MEASURE</i>				

Start data menu

Flux/Gas pre-flow is active if the chosen start type is scratch. Start signal (relay output 2) will be generated, and when pre-flow time has elapsed travel will start. When start type direct is chosen, pre-flow has no function.

SAW START DATA				
FLUX PREFLOW			0.0 s	
START TYPE			DIRECT	
MEASURE				

Scratch start will start a travel and generate start signal out at the same time when the start button is pressed. Pre-flow has no function.

When starting relay output 2, a direct start will be generated, but travel will not start until digital input for current flow is active. So if no input on I/O ATAS for current flow, use scratch start instead.

SAW START DATA				
FLUX PREFLOW			0.0 s	
START TYPE			SCRATCH	
MEASURE				

Measure menu

In the measure menu, you can see measure values for travel speed and jog wire speed. The wire motor is not started when you press the start button on the control unit, but you can use that motor for other work. In the setting menu, you can also set travel speed.

SAW: CW FE SOLID				■ 7
NONE	DIR. SQUARE	NONE	SET VALUES	2ND FUNCT


Remote and external axis

Remote via ATAS I/O and external axis for controlling a roller bed can also be used together with motor control.

SAW 0.8 mm : EXT				■ 7
REMOTE IO	DIR. SQUARE	EXT. AXIS	SET VALUES	2ND FUNCT

Machine configuration

With product code motor control you can set gearing as with user defined axis on wire feed, travel and external axis.


<i>MACHINE CONFIGURATION</i>				
<i>PRODUCT CODE</i>			<i>Motor control</i>	
<i>WIRE FEED AXIS 1 ▶</i>				
<i>TRAVEL AXIS ▶</i>				
<i>EXTERNAL AXIS ▶</i>				

Motor card

Start signal to external equipment's as the power source is located on connector X1.15-16.

APPENDIX

ORDERING NUMBERS



Ordering number	Denomination	Type	Notes
0911 492 880	Control unit	EAC 30	
0448 311 *	Control unit, Instruction manual		

Technical documentation is available on the Internet at: www.esab.com

The three last digits in the document number of the manual show the version of the manual. Therefore they are replaced with * here. Make sure to use a manual with a serial number or software version that corresponds with the product, see the front page of the manual.

ACCESSORIES

Ordering number	Denomination	Type	Notes
0465 585 001	USB Memory Stick, 8 GB		

Control Cables

	5 m (16 ft)	19 m (62 ft)	28 m (91 ft)	36 m (118 ft)
Control Cable	0912 061 105	0912 061 119	0912 061 128	0912 061 136
Ethernet Cable (Weldcloud)	0465 816 105	0465 816 119	0465 816 128	0465 816 136



A WORLD OF PRODUCTS AND SOLUTIONS.



For contact information visit <http://esab.com>

ESAB AB, Lindholmsallén 9, Box 8004, 402 77 Gothenburg, Sweden, Phone +46 (0) 31 50 90 00

manuals.esab.com

