

# *LAF 1001 / LAF 1001M*



**Instruction manual**



## DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

The EMC Directive 2004/108/EC, entering into force 20 July 2007

### Type of equipment

Welding power source

### Type designation etc.

LAF 1001, LAF 1001M, from serial number 935 xxx xxxx (2009 w.35)

### Brand name or trade mark

ESAB

### Manufacturer or his authorised representative established within the EEA

Name, address, telephone No, telefax No:

ESAB AB

Esabvägen, SE-695 81 LAXÅ, Sweden

Phone: +46 584 81 000, Fax: +46 584 411 924

### The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1, Arc welding equipment – Part 1: Welding power sources

EN 60974-10, Arc welding equipment – Part 10: Electromagnetic compatibility (EMC) requirements

Additional information: Restrictive use, Class A equipment, intended for use in locations other than residential

**By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.**

Date  
Laxå 2009-09-15

Signature

A handwritten signature in black ink, appearing to read "Kent Eimbrodt". The signature is written in a cursive style with some loops and flourishes.

Kent Eimbrodt  
Clarification

Position  
Global Director  
Equipment and Automation

**1 SAFETY ..... 4**

**2 INTRODUCTION ..... 6**

**3 TECHNICAL DATA ..... 6**

**4 INSTALLATION ..... 7**

    4.1 Location ..... 7

    4.2 Connections ..... 8

**5 OPERATION ..... 9**

    5.1 Controls ..... 9

**6 MAINTENANCE ..... 10**

    6.1 Cleaning ..... 10

**7 ORDERING OF SPARE PARTS ..... 10**

**DIAGRAM ..... 12**

**CONNECTION INSTRUCTION ..... 16**

**ORDERING NUMBER ..... 18**

---

# 1 SAFETY

---

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
  - its operation
  - location of emergency stops
  - its function
  - relevant safety precautions
  - welding and cutting
2. The operator must ensure that:
  - no unauthorised person is stationed within the working area of the equipment when it is started up.
  - no-one is unprotected when the arc is struck
3. The workplace must:
  - be suitable for the purpose
  - be free from drafts
4. Personal safety equipment
  - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves.
  - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
  - Make sure the return cable is connected securely.
  - Work on high voltage equipment **may only be carried out by a qualified electrician.**
  - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
  - Lubrication and maintenance must **not** be carried out on the equipment during operation.



## CAUTION

*This product is solely intended for arc welding.*



# WARNING



**Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.**

**ELECTRIC SHOCK - Can kill**

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

**FUMES AND GASES - Can be dangerous to health**

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

**ARC RAYS - Can injure eyes and burn skin.**

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

**FIRE HAZARD**

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

**NOISE - Excessive noise can damage hearing**

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

**MALFUNCTION - Call for expert assistance in the event of malfunction.**


**Read and understand the instruction manual before installing or operating.**

**PROTECT YOURSELF AND OTHERS!**





## CAUTION

*Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.*



## CAUTION

*Read and understand the instruction manual before installing or operating.*



**Dispose of electronic equipment at the recycling facility!**

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.

**ESAB can provide you with all necessary welding protection and accessories.**

## 2 INTRODUCTION

**LAF 1001/ LAF 1001M** are remote-controlled 3-phase welding power sources intended for highly productive mechanised gas metal arc welding (MIG/MAG) or submerged arc welding (SAW).

The welding power sources are fan-cooled and are monitored by a thermal cutout against overload. When the thermal cutout is deployed the yellow lamp on the front panel illuminates automatically. The reset is carried out automatically when the temperature has decreased to a permitted level.

## 3 TECHNICAL DATA

	<b>LAF 1001</b>	<b>LAF 1001M</b>
<b>Mains connection:</b>	400/415/500 V, 3~50 Hz 400/440/550 V, 3~60 Hz	230/400/415/500 V, 3~50 Hz 230/400/440/550 V, 3~60 Hz
<b>Primary current</b>	$I_{max}$ 80 A	$I_{max}$ 138 A
<b>Permissible load at:</b>		
100 % duty cycle	800 A/44 V	800 A/44 V
60 % duty cycle	1000 A/44 V	1000 A/44 V
<b>Setting range</b>		
SAW	100-1000 A /24-44 V	100-1000 A /24-44 V
MIG/MAG	100-1000 A /19-44 V	100-1000 A /19-44 V
<b>No-load voltage</b>	53 V	53 V
<b>No-load power</b>	130 W	130 W
<b>Efficiency</b>	88%	88%
<b>Power factor</b>	0,92	0,92
<b>Weight</b>	330 kg	330 kg
<b>Dimensions L x W x H</b>	646 x 552 x 1090	646 x 552 x 1090
<b>Insulation class (transformer):</b>	<b>H</b>	<b>H</b>
<b>Enclosure class</b>	<b>IP 23</b>	<b>IP 23</b>
<b>Application class</b>	<b>S</b>	<b>S</b>

### Enclosure class

The **IP** code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked **IP23** is designed for indoor and outdoor use.

### Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

## 4 INSTALLATION

*The installation must be carried out by a professional.*

### Note

#### Mains supply requirements


High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see technical data). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.

### 4.1 Location




#### WARNING

*Secure the equipment - particularly if the ground is uneven or sloping.*





- Place the welding power source on a level foundation.
- Make sure there is nothing to prevent the cooling.

#### Lifting instructions



## 4.2 Connections

- On delivery the welding power source is connected for 400 V.
- For other supply voltage:  
Remove the left side plate.  
Perform the switchings on the main and control transformer in accordance with the connection instruction on page 16.
- Select the mains cable with the correct cable area and fuse the cable with the correct fuse in accordance with local regulations (see the table on page 8).
- Remove the front plates (x 2).
- Connect the ground cable to the screw marked .
- Tighten the cable clamp (1).
- Connect the mains cables to the main connection terminals L1, L2 and L3 (5).
- Connect the control cable between the welding power source and the control box to the 28-pin connector (2) on the inside of the welding power source.
- Connect the 1-pin measuring cable (4) for measuring the arc voltage to the return cable/welding head.
- Connect a suitable welding and return cable in the connectors (3) marked + and - on the front of the welding power source.
- Fit the side/ front plates.



### Mains connection

LAF 1001	50 Hz			60 Hz		
	Voltage (V)	400	415	500	400	440
Phase current $I_{1\text{eff}}$ (A)	64	64	52	64	64	52
Cable area (mm <sup>2</sup> )	4 x 16	4 x 16	4 x 16	4 x 16	4 x 16	4 x 16
Fuse, slow (A)	63	63	63	63	63	63

LAF 1001M	50 Hz				60 Hz			
	Voltage (V)	230	400	415	500	230	400	440
Phase current $I_{1\text{eff}}$ (A)	111	64	64	52	111	64	64	52
Cable area (mm <sup>2</sup> )	4x50	4 x 16	4 x 16	4 x 16	4x50	4 x 16	4 x 16	4 x 16
Fuse, slow (A)	125	63	63	63	125	63	63	63

**Note:**

The mains cable areas and fuse sizes as shown above are in accordance with Swedish regulations. They may not be applicable in other countries: make sure that the cable area and fuse sizes comply with the relevant national regulations.



## 5 OPERATION


**General safety regulations for handling the equipment can be found on page 4. Read through before you start using the equipment!**





**Note! Never** use the welding power source without side plates.

**Note!** The power source must be set to analogue mode to use the PEI control unit.

### 5.1 Controls

The front panel contains:



1.		<p>Main circuit-breaker for switching the mains voltage and the fan on and off in the welding power source.</p> <ul style="list-style-type: none"> <li>• Position "1" On</li> <li>• Position "0" Off</li> </ul>
2.		<ul style="list-style-type: none"> <li>• The indicator lamp (white) illuminates when the main switch is switched on.</li> </ul>
3.		<p>Indicator lamp for overheating (yellow)</p> <ul style="list-style-type: none"> <li>• The indicator lamp illuminates when the thermal cutout is deployed due to excess temperature in the welding power source.</li> <li>• The indicator lamp goes out when the temperature in the welding power source has decreased to a permitted level.</li> </ul>
4.		<p>Pushbutton resetting the automatic fuse <i>FU2</i> for 42 V supply voltage.</p>

---

## 6 MAINTENANCE

---



### CAUTION

*All guarantee undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the guarantee period.*

### 6.1 Cleaning

#### 6.1.1 Welding power source



### WARNING!

Blocked air inlets or outlets will lead to overheating.

- Clean the welding power source as necessary.  
Dry compressed air is recommended for the purpose.

#### 6.1.2 Contactor



### WARNING!

**Never** use compressed air to clean the contactor without first taking it apart completely.

#### **Note:**

To ensure the reliable operation of the contactor, the magnetic parts must be kept clean.

If the contactor has to be cleaned it **must** be taken apart, and all the pieces be cleaned.

Alternatively, the contactor can be replaced.

---

## 7 ORDERING OF SPARE PARTS

---

*Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.*


**LAF 1001 / LAF 1001M is designed and tested in accordance with the international and European standards 60974-1 and 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.**


Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.




# Diagram


Valid for serial number 935-xxx-xxxx






Valid for serial number 126-xxx-xxxx












# Connection instruction





OMKOPPLING FÖR OLIKA NÄTSPÄNNINGAR.  
 CONNECTIONS FOR DIFFERENT SUPPLY VOLTAGES.  
 SCHALTUNGEN FÜR VERSCHIEDENE NETZSPANNUNGEN.  
 CONNEXIONS POUR DIFFERENTES TENSIONS RESAU.

TC1 SEK. 42V | MAIN TRANSFORMER XT2



0458 012-001

## LAF 1001/ LAF 1001M

### Order number



Ordering no.	Denomination	Type
0460 513 880	Welding power source	LAF 1001
0460 513 881	Welding power source	LAF 1001M
0459 839 057	Spare parts list	LAF 1001 / LAF 1001M

Technical documentation is available on the Internet at [www.esab.com](http://www.esab.com)



# ESAB subsidiaries and representative offices

<b>Europe</b> <b>AUSTRIA</b> ESAB Ges.m.b.H Vienna-Liesing Tel: +43 1 888 25 11 Fax: +43 1 888 25 11 85  <b>BELGIUM</b> S.A. ESAB N.V. Brussels Tel: +32 2 745 11 00 Fax: +32 2 745 11 28  <b>BULGARIA</b> ESAB Kft Representative Office Sofia Tel/Fax: +359 2 974 42 88  <b>THE CZECH REPUBLIC</b> ESAB VAMBERK s.r.o. Vamberk Tel: +420 2 819 40 885 Fax: +420 2 819 40 120  <b>DENMARK</b> Aktieselskabet ESAB Herlev Tel: +45 36 30 01 11 Fax: +45 36 30 40 03  <b>FINLAND</b> ESAB Oy Helsinki Tel: +358 9 547 761 Fax: +358 9 547 77 71  <b>FRANCE</b> ESAB France S.A. Cergy Pontoise Tel: +33 1 30 75 55 00 Fax: +33 1 30 75 55 24  <b>GERMANY</b> ESAB GmbH Solingen Tel: +49 212 298 0 Fax: +49 212 298 218  <b>GREAT BRITAIN</b> ESAB Group (UK) Ltd Waltham Cross Tel: +44 1992 76 85 15 Fax: +44 1992 71 58 03  ESAB Automation Ltd Andover Tel: +44 1264 33 22 33 Fax: +44 1264 33 20 74  <b>HUNGARY</b> ESAB Kft Budapest Tel: +36 1 20 44 182 Fax: +36 1 20 44 186  <b>ITALY</b> ESAB Saldatura S.p.A. Bareggio (Mi) Tel: +39 02 97 96 8.1 Fax: +39 02 97 96 87 01  <b>THE NETHERLANDS</b> ESAB Nederland B.V. Amersfoort Tel: +31 33 422 35 55 Fax: +31 33 422 35 44	<b>NORWAY</b> AS ESAB Larvik Tel: +47 33 12 10 00 Fax: +47 33 11 52 03  <b>POLAND</b> ESAB Sp.zo.o. Katowice Tel: +48 32 351 11 00 Fax: +48 32 351 11 20  <b>PORTUGAL</b> ESAB Lda Lisbon Tel: +351 8 310 960 Fax: +351 1 859 1277  <b>ROMANIA</b> ESAB Romania Trading SRL Bucharest Tel: +40 316 900 600 Fax: +40 316 900 601  <b>RUSSIA</b> LLC ESAB Moscow Tel: +7 (495) 663 20 08 Fax: +7 (495) 663 20 09  <b>SLOVAKIA</b> ESAB Slovakia s.r.o. Bratislava Tel: +421 7 44 88 24 26 Fax: +421 7 44 88 87 41  <b>SPAIN</b> ESAB Ibérica S.A. Alcalá de Henares (MADRID) Tel: +34 91 878 3600 Fax: +34 91 802 3461  <b>SWEDEN</b> ESAB Sverige AB Gothenburg Tel: +46 31 50 95 00 Fax: +46 31 50 92 22  ESAB international AB Gothenburg Tel: +46 31 50 90 00 Fax: +46 31 50 93 60  <b>SWITZERLAND</b> ESAB AG Dietikon Tel: +41 1 741 25 25 Fax: +41 1 740 30 55  <b>UKRAINE</b> ESAB Ukraine LLC Kiev Tel: +38 (044) 501 23 24 Fax: +38 (044) 575 21 88	<b>North and South America</b> <b>ARGENTINA</b> CONARCO Buenos Aires Tel: +54 11 4 753 4039 Fax: +54 11 4 753 6313  <b>BRAZIL</b> ESAB S.A. Contagem-MG Tel: +55 31 2191 4333 Fax: +55 31 2191 4440  <b>CANADA</b> ESAB Group Canada Inc. Mississauga, Ontario Tel: +1 905 670 02 20 Fax: +1 905 670 48 79  <b>MEXICO</b> ESAB Mexico S.A. Monterrey Tel: +52 8 350 5959 Fax: +52 8 350 7554  <b>USA</b> ESAB Welding & Cutting Products Florence, SC Tel: +1 843 669 44 11 Fax: +1 843 664 57 48  <b>Asia/Pacific</b> <b>AUSTRALIA</b> ESAB South Pacific Archerfield BC QLD 4108 Tel: +61 1300 372 228 Fax: +61 7 3711 2328  <b>CHINA</b> Shanghai ESAB A/P Shanghai Tel: +86 21 2326 3000 Fax: +86 21 6566 6622  <b>INDIA</b> ESAB India Ltd Calcutta Tel: +91 33 478 45 17 Fax: +91 33 468 18 80  <b>INDONESIA</b> P.T. ESABindo Pratama Jakarta Tel: +62 21 460 0188 Fax: +62 21 461 2929  <b>JAPAN</b> ESAB Japan Tokyo Tel: +81 45 670 7073 Fax: +81 45 670 7001  <b>MALAYSIA</b> ESAB (Malaysia) Snd Bhd USJ Tel: +603 8023 7835 Fax: +603 8023 0225  <b>SINGAPORE</b> ESAB Asia/Pacific Pte Ltd Singapore Tel: +65 6861 43 22 Fax: +65 6861 31 95	<b>SOUTH KOREA</b> ESAB SeAH Corporation Kyungnam Tel: +82 55 269 8170 Fax: +82 55 289 8864  <b>UNITED ARAB EMIRATES</b> ESAB Middle East FZE Dubai Tel: +971 4 887 21 11 Fax: +971 4 887 22 63  <b>Africa</b> <b>EGYPT</b> ESAB Egypt Dokki-Cairo Tel: +20 2 390 96 69 Fax: +20 2 393 32 13  <b>SOUTH AFRICA</b> ESAB Africa Welding & Cutting Ltd Durbanvill 7570 - Cape Town Tel: +27 (0)21 975 8924  <b>Distributors</b> <i>For addresses and phone numbers to our distributors in other countries, please visit our home page</i>  <a href="http://www.esab.com">www.esab.com</a>
---	--	--	---



[www.esab.com](http://www.esab.com)

