

Buddy™

Arc 180

Arc 200



Instruction manual



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

The EMC Directive 2004/108/EC, entering into force 20 July 2007

The RoHS Directive 2011/65/EC, entering onto force 2 January 2013

Type of equipment

Welding power source

Type designation etc.

Buddy™ Arc 180, Stock code 0700300680, from serial number 31312108277

Buddy™ Arc 200, Stock code 0700300887, from serial number 31312108187

Brand name or trade mark

ESAB

Manufacturer or his authorised representative established within the EEA

Name, address, telephone No:

ESAB AB
Lindholmsallén 9,
Box 8004,
SE-402 77 Göteborg,
Sweden

Phone: +46 31 50 90 00, Fax: +46 584 411 924

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1, Arc Welding Equipment – Part 1: Welding Power Sources

EN 60974-10, Arc Welding Equipment – Part 10: Electromagnetic Compatibility (EMC) requirements

Additional Information: Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date 2014-01-17
Gothenburg

Signature

A handwritten signature in blue ink, appearing to read "Stephen Argo", is written over the printed name.

Stephen Argo

Clarification

Position

Global Director

Equipment

1	SAFETY	4
2	INTRODUCTION	7
2.1	Equipment.....	7
3	TECHNICAL DATA	8
4	INSTALLATION.....	9
4.1	Location	9
4.2	Mains power supply	9
4.2.1	Recommended fuse sizes and minimum cable area	9
5	OPERATION	10
5.1	Connections	10
5.2	Connection of welding and return cable.....	10
5.3	Symbols and Control panels.....	11
5.4	Overheating protection.....	11
5.5	MMA welding	11
5.5.1	Welding current setting	12
5.5.2	Striking the arc	12
5.5.3	Manipulation of electrode	12
5.5.4	Anti-electrode pick-up	13
5.5.5	Joint forms in MMA	13
5.5.6	Electrode selection.....	13
5.6	TIG welding.....	13
5.6.1	Welding current setting	14
5.6.2	Striking an Arc "Live TIG- start".....	14
5.6.3	Joint forms in TIG.....	14
6	MAINTENANCE	15
6.1	Power source.....	15
6.2	Welding torch	15
7	FAULT-TRACING	16
8	ORDERING SPARE PARTS	17
	DIAGRAM	18
	ORDERING NUMBERS	20
	ACCESSORIES	21

1 SAFETY

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting or other applicable operation of the equipment
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up
 - no-one is unprotected when the arc is struck or work is started with the equipment
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts
4. Personal safety equipment:
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns
5. General precautions:
 - Make sure the return cable is connected securely
 - Work on high voltage equipment **may only be carried out by a qualified electrician**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand
 - Lubrication and maintenance must **not** be carried out on the equipment during operation

**WARNING!**

Do not use the power source for thawing frozen pipes.

**WARNING!**

Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing
- Insulate yourself from earth and the workpiece
- Ensure your working stance is safe

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area

ARC RAYS - Can injure eyes and burn skin

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing
- Protect bystanders with suitable screens or curtains

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby

NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk

MALFUNCTION - Call for expert assistance in the event of malfunction.

Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!

**CAUTION!**

Read and understand the instruction manual before installing or operating.

**CAUTION!**

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.

**CAUTION!**

This product is solely intended for arc welding.

ESAB can provide you with all necessary welding protection and accessories.

DISMANTLING AND SCRAPPING



NOTE!

Dispose of electronic equipment at the recycling facility!

In observance of European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



Welding equipment primarily consists of steel, plastic and non-ferrous metals, and must be handled according to local environmental regulations.

Coolant must also be handled according to local environmental regulations.

2 INTRODUCTION

Arc 180 and Arc 200 are welding power sources intended for use with coated electrodes (MMA welding) and TIG welding (Live Arc).

ESAB's accessories for the product can be found in the "ACCESSORIES" chapter of this manual.

2.1 Equipment

The power source is supplied with:

- 3 meter welding cable with electrode holder
- 3 meter return cable with return clamp
- Instruction manual

3 TECHNICAL DATA

	Arc 180	Arc 200
Mains voltage	230 V 1~ ± 10 %, 50/60 Hz	230 V 1~ ± 10 %, 50/60 Hz
Primary current I_{max}	36 A	40.7 A
Setting range MMA	5 A / 20.0 V - 180 A / 27.2 V	5 A / 20.2 V - 210 A / 28.4 V
Setting range TIG	5 A / 10 V - 180 A / 17.2 V	5 A / 10.2 V - 210 A / 18.4 V
Permissible load at MMA		
30 % duty cycle	180 A / 27.2 V	
35 % duty cycle		200 A / 28.0 V
60 % duty cycle	125 A / 25.2 V	135 A / 25.4 V
100 % duty cycle	100 A / 24.0 V	120 A / 24.8 V
Permissible load at TIG		
35 % duty cycle	180 A / 17.2 V	200 A / 18.0 V
60 % duty cycle	130 A / 15.2 V	135 A / 15.4 V
100 % duty cycle	100 A / 14.0 V	120 A / 14.8 V
Power factor at maximum current	0.72	0.71
Efficiency at maximum current	>80 %	>80 %
Open-circuit voltage U ₀ max	59.8 V	66.3 V
Operating temperature	-10 to +40°C	-10 to +40°C
Transportation temperature	-20 to +55°C	-20 to +55°C
Sound pressure at no-load	<70 db (A)	<70 db (A)
Dimensions l × w × h	310 × 140 × 230 mm	360 × 140 × 230 mm
Weight	6.6 kg	7.5 kg
Enclosure class	IP 23S	IP 23S
Application class	S	S

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40°C / 104°F.

Enclosure class

The **IP** code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.

Application class

The symbol S indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION



The installation must be carried out by a professional.

4.1 Location

Position the power source such that its cooling air inlets and outlets are not obstructed. Also position the power source so that the air inlet does not get clogged with unwanted material.

4.2 Mains power supply

Make sure that the welding power source is connected to the correct supply voltage and that it is protected by the correct fuse rating. The outlet shall have a protective earth connection.



A. Rating plate with supply connection data

4.2.1 Recommended fuse sizes and minimum cable area

	Arc 180	Arc 200
Mains voltage	230V 1~ ± 10%, 50/60 Hz	
Mains cable area mm ²	3 G 2.5	3 G 2.5
Phase current $I_{1\text{eff}}$ (TIG)	12.5 A	16.6 A
Phase current $I_{1\text{eff}}$ (MMA)	16.0 A	24.1 A




NOTE!

Use the power source in accordance with the relevant national regulations.

5 OPERATION

General safety regulations for handling the equipment can be found in the "SAFETY" chapter of this manual. Read it through before you start using the equipment!

5.1 Connections



- | | |
|--|----------------------------------|
| 1. Control panel | 4. Mains power supply switch 1/O |
| 2. Connection (-) for return cable, welding cable or TIG torch | 5. Connection for mains cable |
| 3. Connection (+) for return cable or welding cable | |

5.2 Connection of welding and return cable

The power source has two outputs, a negative [-] terminal (2) and a positive [+] terminal (3), for connecting welding and return cables.


For MMA process the output to which the welding cable is connected depends on the type of electrode, please refer to electrode packaging for information relating to the correct electrode polarity.

For optional TIG process, connect the TIG torch power cable to the negative [-] terminal (2). Connect gas inlet nut to a regulated shielding gas supply.



Connect the return cable to the remaining welding terminal on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact.

5.3 Symbols and Control panels

Arc 180



Arc 200



Power ON Indicating lamp,
white, power supply ON



Scratch TIG



Overheating Indicating lamp,
yellow, overheating



MMA welding

5.4 Overheating protection


The welding power source has a thermal overload trip which operates if the temperature becomes too high, interrupting the welding current and lighting a yellow indicating lamp on the front of the power source. The thermal overload trip resets automatically when the temperature has fallen.



NOTE!

If the utilization of the power source is too high it might get overheated. See permissible load in the TECHNICAL DATA chapter in this manual.

If the air inlet or outlet is blocked or gets clogged with unwanted material the power source might get overheated. Make sure that the airflow through the power source is not blocked.



5.5 MMA welding

Move process selector switch to desired welding process.

**NOTE!**


Power source output is enabled.

Check welding cable polarity selection matches electrode requirements. Select desired welding current level.

5.5.1 Welding current setting

The Arc 180 power source has an adjustable welding current from 5 to 180 Amps.

The Arc 200 has an adjustable value from 5 to 200 Amps.



Current

5.5.2 Striking the arc


MMA welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.

If, when striking the arc, the tip of the electrode is pressed against the metal, it immediately melts and sticks to the metal, rendering continued welding impossible. Therefore, the arc has to be struck in the same way that you would light a match. Quickly strike the electrode against the metal and then raise it to give an appropriate arc length (approx. 2 mm). If the arc is too long, it will crackle and split before finally going out completely. Once the arc has been struck, move the electrode from left to right. The electrode should be at an angle of 60° to the metal.

5.5.3 Manipulation of electrode

In MMA welding, there are three motions to being matched in the end of electrode: the electrode moving to the molten pool along axes [1]; a small oscillation maybe necessary to achieve the desired width of the melt pool [2]; the electrode moving along welding way [3].

The operator can choose the manipulation of electrode based on welding joint sharp, welding position, electrode spec, welding current and operation skill, etc.




- | | |
|---|--------------|
| 1. electrode moving | 4. workpiece |
| 2. the electrode oscillation (right and left) | 5. weld |
| 3. the electrode move along weld | 6. electrode |

5.5.4 Anti-electrode pick-up

If, during the welding, the electrode would get in direct contact (touching) with the workpiece to form short circuit, the welding current will drop to a minimum to prolong the life of the electrode.

5.5.5 Joint forms in MMA



5.5.6 Electrode selection

The electrode diameter selection is based on the workpiece thickness, welding position, joint form, welding layer, etc. Please refer to the recommendations on the electrode package for further details.

- To ensure good quality weld, the electrode should always be dried or dry stored. This to avoid hydrogen inclusion, blowholes and cold cracks.
- In the welding process, the arc must not be too long; otherwise, it will cause unstable arc burning, large spatter, light penetration, undercut, blowhole, etc. If the arc is too short, it will cause electrode stick.



5.6 TIG welding

TIG welding melts the metal of the workpiece, using an arc struck from a tungsten electrode, which does not itself melt. The weld pool and the electrode are protected by shielding gas.

TIG welding is particularly useful where high quality is demanded and for welding thin plate. The power sources also have good characteristics for TIG welding.

In order to TIG weld, the power sources must be equipped with:

- a TIG torch with gas valve (see in the "ACCESSORIES" chapter of this manual)
- a welding gas cylinder (a suitable welding gas)
- a welding gas regulator (suitable gas regulator)
- tungsten electrode
- suitable auxiliary material, if necessary.

Move process selector switch to desired welding process.

**NOTE!**


Power source output is enabled.

Check welding cable and TIG torch polarity matches electrode requirements.

Select desired welding current level.

5.6.1 Welding current setting


The Arc 180 power source has an adjustable welding current from 5 to 180 Amps. The Arc 200 has an adjustable value from 5 to 200 Amps.




Current

5.6.2 Striking an Arc “Live TIG- start”

With “Live TIG start” the arc strikes when the tungsten electrode is brought into contact with the workpiece and then lifted away from it.



5.6.3 Joint forms in TIG



6 MAINTENANCE



NOTE!

Regular maintenance is important for safe, reliable operation.



CAUTION!

Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates.



CAUTION!

All warranty undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the warranty period.

6.1 Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on:

- welding process
- arc time
- placement
- surrounding environment

It is normally sufficient to blow the power source with dry compressed air (reduced pressure) once a year.


Clogged or blocked air inlets and outlets otherwise result in overheating.

6.2 Welding torch

Wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

7 FAULT-TRACING

Try these recommended checks and inspections before sending for an authorized service technician.

Type of fault	Corrective action
No arc.	• Check that the mains power supply switch is turned on. • Check That the mains input Voltage is not too low or too high. The yellow LED will illuminate if the input is below or above the recommended levels and the machine is at normal working temperature. • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check to see whether the MCB has tripped.
The welding current is interrupted during welding.	• Check whether the thermal cut-outs have tripped (indicated by the yellow lamp on the front panel). • Check the mains power supply fuses.
The thermal cut-out trips frequently.  	• Check to see whether the dust filter is clogged. • Make sure that you are not exceeding the rated data for the power source (i.e. that the unit is not being overloaded). See permissible load in the TECHNICAL DATA chapter in this manual. • Make sure that the positioning of the power source is such that its cooling air inlets and outlets are not obstructed.
Poor welding performance.	• Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used. • Check the gas flow. When in Live Tig Mode using optional ET 17V Tig Torch.

8 ORDERING SPARE PARTS




CAUTION!


Repair and electrical work should be performed by an authorised service technician. Use only original spare and wear parts.

Arc 180, Arc 200 is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

DIAGRAM









ORDERING NUMBERS



Ordering no.	Denomination	Type
0700 300 885	Welding power source	Buddy™ Arc 180
0700 300 887	Welding power source	Buddy™ Arc 200
0459 839 066	Spare parts list	Buddy™ Arc 180 and Arc 200

Technical documentation is available on the Internet at: www.esab.com

ACCESSORIES

0700 006 901	Return cable with clamp 200A, OKC 50, 3m	
0700 006 885	Return cable with clamp 200A, OKC 50, 5m	
0700 006 900	Welding cable 200A, OKC 50, 3m	
0700 006 884	Welding cable 200A, OKC 50, 5m	
0700 300 861	TIG 17 torch 4 m	

ESAB subsidiaries and representative offices

Europe

AUSTRIA

ESAB Ges.m.b.H
Vienna-Liesing
Tel: +43 1 888 25 11
Fax: +43 1 888 25 11 85

BELGIUM

S.A. ESAB N.V.
Heist-op-den-Berg
Tel: +32 15 25 79 30
Fax: +32 15 25 79 44

BULGARIA

ESAB Kft Representative Office
Sofia
Tel: +359 2 974 42 88
Fax: +359 2 974 42 88

THE CZECH REPUBLIC

ESAB VAMBERK s.r.o.
Vamberk
Tel: +420 2 819 40 885
Fax: +420 2 819 40 120

DENMARK

Aktieselskabet ESAB
Herlev
Tel: +45 36 30 01 11
Fax: +45 36 30 40 03

FINLAND

ESAB Oy
Helsinki
Tel: +358 9 547 761
Fax: +358 9 547 77 71

GREAT BRITAIN

ESAB Group (UK) Ltd
Waltham Cross
Tel: +44 1992 76 85 15
Fax: +44 1992 71 58 03

ESAB Automation Ltd
Andover
Tel: +44 1264 33 22 33
Fax: +44 1264 33 20 74

FRANCE

ESAB France S.A.
Cergy Pontoise
Tel: +33 1 30 75 55 00
Fax: +33 1 30 75 55 24

GERMANY

ESAB GmbH
Solingen
Tel: +49 212 298 0
Fax: +49 212 298 218

HUNGARY

ESAB Kft
Budapest
Tel: +36 1 20 44 182
Fax: +36 1 20 44 186

ITALY

ESAB Saldatura S.p.A.
Bareggio (Mi)
Tel: +39 02 97 96 8.1
Fax: +39 02 97 96 87 01

THE NETHERLANDS

ESAB Nederland B.V.
Amersfoort
Tel: +31 33 422 35 55
Fax: +31 33 422 35 44

NORWAY

AS ESAB
Larvik
Tel: +47 33 12 10 00
Fax: +47 33 11 52 03

POLAND

ESAB Sp. z o.o.
Katowice
Tel: +48 32 351 11 00
Fax: +48 32 351 11 20

PORTUGAL

ESAB Lda
Lisbon
Tel: +351 8 310 960
Fax: +351 1 859 1277

ROMANIA

ESAB Romania Trading SRL
Bucharest
Tel: +40 316 900 600
Fax: +40 316 900 601

RUSSIA

LLC ESAB
Moscow
Tel: +7 (495) 663 20 08
Fax: +7 (495) 663 20 09

SLOVAKIA

ESAB Slovakia s.r.o.
Bratislava
Tel: +421 7 44 88 24 26
Fax: +421 7 44 88 87 41

SPAIN

ESAB Ibérica S.A.
Alcalá de Henares (MADRID)
Tel: +34 91 878 3600
Fax: +34 91 802 3461

SWEDEN

ESAB Sverige AB
Gothenburg
Tel: +46 31 50 95 00
Fax: +46 31 50 92 22

ESAB International AB
Gothenburg
Tel: +46 31 50 90 00
Fax: +46 31 50 93 60

SWITZERLAND

ESAB AG
Dietikon
Tel: +41 1 741 25 25
Fax: +41 1 740 30 55

UKRAINE

ESAB Ukraine LLC
Kiev
Tel: +38 (044) 501 23 24
Fax: +38 (044) 575 21 88

North and South America

ARGENTINA

CONARCO
Buenos Aires
Tel: +54 11 4 753 4039
Fax: +54 11 4 753 6313

BRAZIL

ESAB S.A.
Contagem-MG
Tel: +55 31 2191 4333
Fax: +55 31 2191 4440

CANADA

ESAB Group Canada Inc.
Mississauga, Ontario
Tel: +1 905 670 02 20
Fax: +1 905 670 48 79

MEXICO

ESAB Mexico S.A.
Monterrey
Tel: +52 8 350 5959
Fax: +52 8 350 7554

USA

ESAB Welding & Cutting
Products
Florence, SC
Tel: +1 843 669 44 11
Fax: +1 843 664 57 48

Asia/Pacific

AUSTRALIA

ESAB South Pacific
Archerfield BC QLD 4108
Tel: +61 1300 372 228
Fax: +61 7 3711 2328

CHINA

Shanghai ESAB A/P
Shanghai
Tel: +86 21 2326 3000
Fax: +86 21 6566 6622

INDIA

ESAB India Ltd
Calcutta
Tel: +91 33 478 45 17
Fax: +91 33 468 18 80

INDONESIA

P.T. ESABindo Pratama
Jakarta
Tel: +62 21 460 0188
Fax: +62 21 461 2929

JAPAN

ESAB Japan
Tokyo
Tel: +81 45 670 7073
Fax: +81 45 670 7001

MALAYSIA

ESAB (Malaysia) Snd Bhd
USJ
Tel: +603 8023 7835
Fax: +603 8023 0225

SINGAPORE

ESAB Asia/Pacific Pte Ltd
Singapore
Tel: +65 6861 43 22
Fax: +65 6861 31 95

SOUTH KOREA

ESAB SeAH Corporation
Kyungnam
Tel: +82 55 269 8170
Fax: +82 55 289 8864

UNITED ARAB EMIRATES

ESAB Middle East FZE
Dubai
Tel: +971 4 887 21 11
Fax: +971 4 887 22 63

Africa

EGYPT

ESAB Egypt
Dokki-Cairo
Tel: +20 2 390 96 69
Fax: +20 2 393 32 13

SOUTH AFRICA

ESAB Africa Welding & Cutting
Ltd
Durbanvill 7570 - Cape Town
Tel: +27 (0)21 975 8924

Distributors

For addresses and phone numbers to our distributors in other countries, please visit our home page

www.esab.com