


Rogue ES 201i



Spare parts list

Ordering no.	Denomination	Notes
4610210201	Rogue ES 201i	Welding power source
0448 336 001	Rogue ES 201i	Instruction manual
0448 498 001	Rogue ES 201i	Spare parts list

Spare parts may be ordered through your nearest ESAB dealer, see esab.com. When ordering, please state product type, serial number, denominations and ordering numbers according to the spare parts list. This facilitates dispatch and ensures correct delivery.


Maintenance and repair work should be performed by an experienced person, and electrical work only by a trained electrician. Use only recommended spare parts.

For accessories to the product, see the instruction manual.

The three last digits in the document number of the manual show the version of the manual. Therefore they are replaced with * here. Make sure to use a manual with a serial number or software version that corresponds with the product, see the front page of the manual.

1 SPARE PARTS

Item	Ordering no.	Denomination
1	30602120	Transformer bracket
2	3040000027	Left output bronze medal
3	3040000028	Right output bronze medal
4	30501534	Rectifier component
5	30501531	Inverter component
6	40134011	Iron studs
7	11509031	Switch
8	50802001	Power cable connector
9	0011702037	Fan
10	6020100003	Rear panel
11	6020600001	Handle
12	3040000032	Case
13	0030101283	Filter board
14	3040000033	Base plate
15	0031001041	Auxiliary inductor
16	0050804024	Output terminal
17	6021000001	Potentiometer knob
18	3040000035	Display board sheet with label
19	3010000009	Control board
20	6020100001	Air input cover
21	6020100002	Front panel
22	60701064	Radiator insulation strut
23	60701075	Radiator connector





A WORLD OF PRODUCTS AND SOLUTIONS.



For contact information visit <http://esab.com>

ESAB AB, Lindholmsallén 9, Box 8004, 402 77 Gothenburg, Sweden, Phone +46 (0) 31 50 90 00

<http://manuals.esab.com>

