

Renegade VOLT ES 200i




<p>1</p> <p>TX-20 x4 M5x16 6 Nm / 53.1 in. lb</p>	<p>2</p>	
<p>3a</p> <p>MMA +/-</p>	<p>3b</p> <p>Live TIG -</p>	<p>4</p>
<p>5a</p> <p>Mains Mode</p> <p>120/230VAC 1~ 50/60Hz</p>	<p>5b</p>	<p>5c</p>


Quick Start Guide

0447 812 001 GB 20230921

Renegade VOLT ES 200i




WE CARE ABOUT THE ENVIRONMENT
FIND YOUR MANUAL ONLINE
manuals.esab.com

For contact information visit esab.com

ESAB Group Inc, 2800 Airport Rd. Denton, TX 76207 USA, Telephone:1-800-426-1888
 ESAB AB, Lindholmsallén 9, Box 8004, 402 77 Gothenburg, Sweden, Phone +46 (0) 31 50 90 00

manuals.esab.com

